

PRICE \$15.00

SERVICE BULLETIN 8804-6  
April, 1987

**SQUARE D<sup>®</sup>**

**omegapak<sup>®</sup>**  
*Adjustable Frequency Controller*

*Variable Torque*

**PUMP & FAN**

**1 - 25 HORSEPOWER VARIABLE TORQUE  
30 - 50 HORSEPOWER VARIABLE TORQUE**

## CONTENTS

**NOTE:** This service bulletin covers the installation, start-up and servicing of standard controllers and controllers with pre-engineered options. Controllers having variations or special options will be furnished with a set of record drawings which must be consulted to properly and safely install, start-up or service the controller.

### 1.0 GENERAL

- 1.1 PRECAUTIONS
- 1.2 PRELIMINARY INSPECTION
- 1.3 STORAGE
- 1.4 CONTROLLER IDENTIFICATION
- 1.5 KITS FOR FIELD INSTALLATION

### 2.0 INSTALLATION

- 2.1 MECHANICAL INSTALLATION
- 2.2 ELECTRICAL INSTALLATION
  - 2.2.1 INPUT POWER
    - 2.2.2.A INPUT WIRING
    - 2.2.2.B DISCONNECT DEVICES
  - 2.2.3 OUTPUT POWER
  - 2.2.4 CONTROL WIRING
  - 2.2.5 WIRING PRACTICE

### 3.0 APPLICATION DATA

- 3.1 BASIC CONTROLLER
  - 3.1.1 INPUT
  - 3.1.2 OUTPUT
  - 3.1.3 PERFORMANCE
  - 3.1.4 ENVIRONMENTAL CONDITIONS
  - 3.1.5 ADJUSTMENTS
  - 3.1.6 PROTECTION
  - 3.1.7 DIAGNOSTIC AND STATUS INDICATORS
- 3.2 OPTIONS
  - 3.2.1 CONTROLLER MOUNTED PILOT DEVICES
  - 3.2.2 OUTPUT ISOLATION CONTACTOR
  - 3.2.3 ISOLATION AND BYPASS CONTACTORS
  - 3.2.4 CIRCUIT BREAKER DISCONNECT
  - 3.2.5 FUSIBLE DISCONNECT SWITCH
  - 3.2.6 METERS

### 4.0 CONTROLLER PHOTOS

- 4.1 OMEGAPAK 1000 CONTROLLER
- 4.2 OMEGAPAK 2000 CONTROLLER

### 5.0 INITIAL START-UP PROCEDURE

- 5.1 START-UP PROCEDURE

### 6.0 CONTROLLER ADJUSTMENTS

- 6.1 MAIN CONTROL BOARD ADJUSTMENTS
  - 6.1.1 INPUT VOLTAGE SELECTION
  - 6.1.2 INPUT FREQUENCY SELECTION
  - 6.1.3 CONTROLLER FAULT LOCK-OUT SELECTION
  - 6.1.4 CONSTANT OR VARIABLE VOLTZ/HZ SELECTION
  - 6.1.5 CONTROLLED/UNCONTROLLED STOP SEQUENCE
  - 6.1.6 POTENTIOMETER ADJUSTMENTS
- 6.2 METER ADJUSTMENTS
  - 6.2.1 ANALOG SPEED METER
  - 6.2.2 DIGITAL SPEED METER
  - 6.2.3 ANALOG VOLTMETER
  - 6.2.4 DIGITAL VOLTMETER
  - 6.2.5 ANALOG AMMETER
  - 6.2.6 DIGITAL AMMETER

### 7.0 DIAGNOSTIC AND STATUS INDICATING LIGHTS

- 7.1 MAIN CONTROL BOARD
- 7.2 GATE DRIVER BOARD
- 7.3 POWER INTERFACE BOARD
- 7.4 STANDBY MODE LAMP STATUS

### 8.0 POTENTIOMETER, SELECTION SWITCH, LED AND SNIP-OUT COMPONENT PLACEMENT CHART

- 8.1 MAIN CONTROL BOARD

### 9.0 CONTROLLER OPERATION

- 9.1 BLOCK DIAGRAM DESCRIPTION
- 9.2 CONTROL CIRCUIT SEQUENCE
  - 9.2.1 PILOT LIGHTS, ELAPSED TIME METER, HEAT SINK FAN(S)

- 9.2.2 START-STOP PUSH BUTTONS
- 9.2.3 HAND/AUTO SELECTOR SWITCH AND START STOP
- 9.2.4 HAND-OFF-AUTO SELECTOR SWITCH
- 9.2.5 HAND-OFF-AUTO SELECTOR SWITCH, AND ISOLATION OR ISOLATION/BYPASS CONTACTORS.

**10.0 TROUBLESHOOTING AND MAINTENANCE GUIDE (REFER TO SECTION 10 FOR CONTENTS)**

**11.0 CONTROLLER DRAWINGS (REFER TO SECTION 11 FOR CONTENTS)**

**12.0 RENEWAL PARTS LIST**

## 1.0 GENERAL

### 1.1 PRECAUTIONS

The following list of "PRECAUTIONS" must be studied and followed during the installation, operation, and servicing of the equipment.

1. Read this service bulletin prior to installing or operating the equipment.
2. Service work should be performed only after becoming familiar with all listed danger and caution statements.
3. If OMEGAPAK controllers are to be stored prior to installation, they must be protected from the weather and kept free of condensation and dust.
4. Use extreme care when moving or positioning controllers (even if crated) as they contain devices and mechanisms which may be damaged by rough handling.
5. Only authorized personnel should be permitted to operate or service the controller.
6. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.
7. Do not make any modifications to this controller other than those described in this manual. Doing so may damage or degrade the apparatus.

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**BEFORE SERVICING, TURN OFF POWER**  
**SUPPLY(S) TO THIS EQUIPMENT. WAIT 5**  
**MINUTES. MEASURE CAPACITOR VOLTAGES**  
**TO VERIFY THAT THEY ARE ZERO. DO NOT**  
**SHORT ACROSS CAPACITORS WITH**  
**VOLTAGE PRESENT.**

The dc bus capacitors are discharged slowly when input power is removed from the OMEGAPAK controller. To ensure the capacitors are fully discharged, always test with a dc voltmeter (1000vdc scale) before doing any wiring, troubleshooting or work inside the controller enclosure. If no reading is shown on the voltmeter, reduce scale and test again.

If the capacitors are not fully discharged in 5 minutes, contact Square D — *Do not operate the controller.*

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**MANY PARTS, INCLUDING ELECTRONIC**  
**PRINTED WIRING BOARDS, IN THIS CON-**  
**TROLLER OPERATE AT LINE VOLTAGE. DO**  
**NOT TOUCH. USE ONLY ELECTRICALLY**  
**INSULATED TOOLS WHILE MAKING ADJUST-**  
**MENTS.**

### CAUTION

**DO NOT CHANGE THE POSITION OF ANY PRINTED WIRING BOARD SWITCH OR REMOVE ANY PRINTED WIRING BOARD WITH THE DRIVE RUNNING. TO DO SO MAY CAUSE AN EQUIPMENT MALFUNCTION.**

### 1.2 PRELIMINARY INSPECTION

Inspect for shipping damage upon receiving the OMEGAPAK controller. If any shipping damage is found, immediately notify the freight carrier and your Square D representative. Open the door on the controller and check inside for any visual damage. **DO NOT ATTEMPT TO OPERATE THE CONTROLLER IF ANY VISUAL DAMAGE IS NOTED.** All printed wiring boards should be in place and secure. Check all connectors to be sure they are locked and securely in place.

### 1.3 STORAGE

After the preliminary inspection repack and store the OMEGAPAK controller in a clean dry location. **DO NOT** store this equipment in any area where the ambient temperature will rise above 60°C (140°F) or go below — 17°C (0°F). **DO NOT** store this equipment in high condensation or corrosive atmospheres. Proper storage is required to prevent equipment damage.

### 1.4 CONTROLLER IDENTIFICATION

The OMEGAPAK 1000 Adjustable Frequency Controller is a non-combination (without disconnect device) controller. The controller can be supplied in a wall mounted enclosure or as an

open type unit. The open type 1000 Controller is used as a building block for the OMEGAPAK 2000 and 3000 Controllers.

The OMEGAPAK 2000 and 3000 Adjustable Frequency Controllers are non-combination (without disconnect device) or combination (with disconnect device) controllers depending on a MOD (option) selected.

The 2000 controller is a wall mounted device with space available for open type 1000 controller and selected MOD's (options).

The 3000 controller is a motor control center vertical section with space for 1 or more open type 1000 controllers and selected MOD's (options).

The nameplate for the 1000 controller is located on the inside surface of the controller door. This nameplate is described in Figure 1.1 and carries the 1000 controller class, type, and MOD (options) listing. When identifying 1000 controllers use the data from this nameplate.

The nameplate for the 2000 controller is located on the outside of the vertical wireway


door of the controller enclosure. This nameplate, described in Figure 1.2, carries the controller class, type, and MOD (options) listing. When identifying 2000 controllers use the data from this nameplate.

The nameplate for the 3000 controller is located on the outside of the vertical wireway door of the controller enclosure. This nameplate is described in Service Bulletin 8804-8, a supplement to this service bulletin. An additional label is located on the interior surface of the vertical wireway door of the motor control center enclosure. This label, also described in Service Bulletin 8804-8, lists the 1000 open controllers and MOD's (options) which are installed in the 3000 controller enclosure starting at the top of the enclosure and working down.

To aid in identifying the controller(s), refer to Figures 1.3 and 1.4 for OMEGAPAK 1000 and 2000 controllers and Service Bulletin 8804-8 for OMEGAPAK 3000 controllers. When the controller has been defined, refer to the appropriate section of this Service Bulletin and/or Service Bulletin 8804-8.

FIGURE 1.1

1000 CONTROLLER NAMEPLATE




1000 CONTROLLER NAMEPLATE (LOCATED INSIDE THE DOOR)

- |   |                                  |
|---|----------------------------------|
| 1. CONTROLLER TYPE CODE*                | 7. OUTPUT VOLTAGES               |
| 2. OPTIONS (MOD) CODE**                 | 8. OUTPUT FREQUENCY              |
| 3. PERMISSIBLE INPUT VOLTAGES           | 9. MAX. OUTPUT RATED CURRENT***  |
| 4. MAX. WITHSTAND SYM. AMPS, RMS        | 10. SERVICE FACTOR OF CONTROLLER |
| 5. MAX. INPUT RATED CURRENT***          | 11. FACTORY ORDER NUMBER         |
| 6. HORSEPOWER RATINGS AT INPUT VOLTAGES | 12. DATE CODE                    |
- \* SEE FIGURE 1.3.  
 \*\* SEE FIGURE 1.4.  
 \*\*\* SEE SECTION 2.0, FIGURE 2.1

FIGURE 1.2

2000 CONTROLLER NAMEPLATE



2000 CONTROLLER NAMEPLATE (LOCATED OUTSIDE THE ENCLOSURE)

- |                                      |                         |
|--------------------------------------|-------------------------|
| 1. PERMISSIBLE MAXIMUM INPUT VOLTAGE | 4. FACTORY ORDER NUMBER |
| 2. CONTROLLER TYPE CODE*             | 5. DATE CODE            |
| 3. OPTIONS (MOD) CODE**              | * SEE FIGURE 1.3.       |
|                                      | ** SEE FIGURE 1.4.      |

FIGURE 1.3  
IDENTIFICATION CODE

CLASS 8804, TYPE					-4	
<b>STYLE CONTROLLER</b>						
1000	1					
2000	2					
<b>HORSEPOWER RANGE</b>						
1-25 HP @ 460V		A				
30-50 HP @ 460V		B				
<b>CONTROLLER SYSTEM</b>						
VARIABLE TORQUE RATED			F			
<b>TYPE ENCLOSURE</b>						
NEMA 1				G		
OPEN TYPE				O		
<b>RATING OF CONTROLLER @ 460V</b>						
1 HP						C
2 HP						D
3 HP						E
5 HP						F
7.5 HP						G
10 HP						H
15 HP						J
20 HP						K
25 HP						L
30 HP						M
40 HP						N
50 HP						P

1.5 KITS FOR FIELD INSTALLATION

Controller modifications are available in kit form. Each kit contains necessary hardware and installation instructions.

Description	Kit Number	Kit Installation Instructions	Description	Kit Number	Kit Installation Instructions
Speed Meter (Analog)①	Class 8804, Type AM-1	50006-020-01	Speed Meter, Voltmeter or Ammeter (Digital)①	Class 8804, Type DM-1	50006-020-01
Voltmeter (Analog)①	Class 8804, Type AM-2	50006-020-01	Control Cable Assembly②	Class 8804, Type CK-16	50006-018-01
Ammeter (Analog)①	Class 8804, Type AM-3	50006-020-01			

① Open type. For remote mounting with 1000 controller or as replacement device in 2000 controllers.

② Twelve conductor cable for wiring controller mounted pilot devices.

**FIGURE 1.4  
IDENTIFICATION CODE**

MOD					
<b>GENERAL PURPOSE PILOT DEVICES</b>					
START-STOP, MANUAL SPEED POTENTIOMETERS	S10				
HAND-OFF-AUTO, MANUAL SPEED POTENTIOMETER	H10				
HAND-AUTO, START-STOP, MANUAL SPEED POTENTIOMETER	A10				
<b>DISCONNECT DEVICE</b>					
CIRCUIT BREAKER		C12 <sup>①</sup>			
FUSIBLE SWITCH		D12 <sup>①</sup>			
<b>CONTACTORS</b>					
OUTPUT ISOLATION			C13		
BY-PASS AND ISOLATION WITH CIRCUIT BREAKER STARTER			B13 <sup>①</sup>		
BY-PASS AND ISOLATION WITH FUSIBLE SWITCH STARTER			D13 <sup>①</sup>		
<b>METERING, SPEED-FREQUENCY</b>					
ANALOG SPEED INDICATOR				A14	
DIGITAL SPEED/FREQUENCY INDICATOR				D14	
<b>ADDITIONAL METERING</b>					
ELAPSED TIME METER					T15
ANALOG VOLTMETER					V15
ANALOG AMMETER					A15
ANALOG AMMETER & VOLTMETER					B15
ANALOG VOLTMETER & ELAPSED TIME METER					C15
ANALOG AMMETER & ELAPSED TIME METER					D15
ANALOG AMMETER, VOLTMETER & ELAPSED TIME METER					E15
DIGITAL VOLTMETER					F15
DIGITAL AMMETER					G15
DIGITAL AMMETER & VOLTMETER					H15
DIGITAL VOLTMETER & ELAPSED TIME METER					J15
DIGITAL AMMETER & ELAPSED TIME METER					K15
DIGITAL AMMETER, VOLTMETER & ELAPSED TIME METER					L15
<b>PILOT LIGHTS</b>					
POWER ON LIGHT					P16
RUN LIGHT					R16
DRIVE FAIL LIGHT					F16

① Available for OMEGAPAK 2000 controllers only.

**2.0 INSTALLATION**

**2.1 MECHANICAL INSTALLATION**

The OMEGAPAK controller is mounted in a general purpose NEMA 1 enclosure. It is suitable for use in normal industrial environments:

Temperature range of 0°C to 40°C (32°-104°F)

Humidity range of 0% to 95% maximum non-condensing

Altitude to 3300 ft. above sea level

Do not mount the OMEGAPAK controller in direct sunlight or on hot surfaces. The controller must be mounted vertically to allow for proper ventilation. When drilling for conduit entry, care must be exercised to prevent metal chips from falling on parts and electronic printed wiring boards. Mounting dimensions, conduit entry areas and controller weights are located in Section 11.0 of this service bulletin.

Wall mounted controllers must be securely attached to the mounting surface. The mounting arrangement and surface must be capable of supporting a weight of approximately 150-500 pounds.

Floor mounted controllers are covered in Service Bulletin 8804-8 for motor control centers.

**2.2 ELECTRICAL INSTALLATION**

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**TURN OFF POWER (MAIN AND REMOTE)**  
**PRIOR TO INSTALLING THIS EQUIPMENT**

**2.2.1 INPUT POWER**

The OMEGAPAK controller operates from three phase 460/230/200vac, +10% -5%, 60/50 Hertz, connected to the input disconnect switch. Current limiting fuses are installed in the controller input. These fuses are coordinated with the controller

power circuit for a fault withstand capability of 65,000 RMS symmetrical amperes maximum.

The controller is factory set for 460vac, 60 Hertz input power. If the controller is connected to operate from 230vac, 200vac or 50 Hertz power, refer to the initial start-up procedure (Section 5.0) described in this service bulletin.

**2.2.2.A INPUT WIRING**

The ampacity of power conductors feeding the OMEGPAK controller should be sized for the maximum input currents listed in Figure 2.1, the National Electrical Code and applicable local electrical codes. Refer to Figure 2.4 for lug data and maximum wire size.

**FIGURE 2.1**

<b>MAXIMUM CONTROLLER INPUT AND OUTPUT RATED CURRENTS</b>				
<b>MAXIMUM HORSEPOWER</b>			<b>INPUT AMPERES ①</b>	<b>MAXIMUM CONTINUOUS RATED OUTPUT AMPERES ②</b>
<b>200V</b>	<b>230V</b>	<b>460V</b>		
—	—	1	3.6	2.2
1	1	2	5.6	4.0
1½	1½	3	7.3	5.7
2	2	5	9.7	7.6
3	3	7½	16.3	11.0
—	5	10	19.8	15.2
5	7½	15	29.9	22.0
7½	10	20	39.0	28.0
10	—	25	49.0	34.0
—	15	30	59.0	42.0
15	20	40	78.0	54.0
20	25	50	97.0	68.0

- ① Input currents are maximum values expected. Actual current values could be less depending on the power input source impedance.
- ② Motor nameplate load current must not exceed the maximum continuous output current rating of the controller. For multiple motor applications, the total of the connected motor nameplate load currents must not exceed the controller rated output current.

For safe operation, the controller must be grounded. A terminal on the power terminal board is provided for this purpose.




**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**CONTROLLER PANEL MUST BE PROPERLY**  
**GROUNDED BEFORE APPLYING POWER.**

**Omegapak 1000 Controllers**

Input power leads L1, L2 and L3 are to be connected to terminals provided on the power terminal board. Refer to section 4, Controller photos and Figure 2.2 to determine the configuration of the power terminal board.

**FIGURE 2.2**

**CONTROLLER POWER  
 TERMINAL BOARD**



Refer to Figure 2.4 to determine the range of wire sizes that the terminals will accept and recommended tightening torques. Wires must be based on the maximum input current as shown in the nameplate and listed in Figure 2.1.

**CAUTION**

**DO NOT CONNECT INPUT POWER LEADS TO THE CONTROLLER OUTPUT TERMINALS (T1, T2, T3). DOING SO WILL DAMAGE THE CONTROLLER AND VOID THE WARRANTY.**

**2.2.2.B DISCONNECT DEVICES**

If the OMEGAPAK controller does not have an integral mounted disconnect device (circuit breaker or fusible switch), then one must be provided remotely to meet the National Electrical Code. The disconnect should be sized for maximum input currents listed in Figure 2.4, the National Electrical Code and applicable local electrical codes.

**2.2.3 OUTPUT POWER**

The output voltage is proportional to the output frequency to provide a constant Volts/Hertz ratio in the 20 to 60 Hertz

operating range. Below 20 Hertz the Volts/Hertz ratio will vary depending on the setting of the voltage boost potentiometer.

The ampacity of motor power conductors should be sized according to the motor full load current, National Electrical Code and applicable local electrical codes.

Connect motor conductors to the lugs provided. Refer to Section 4 controller photos for lug location and Figure 2.2 for the configuration of the power terminal board. Refer to Figure 2.4 for data on lugs and maximum wire size and recommended tightening torques. *Do not* connect the output terminals of the controller (T1, T2, or T3) to the L1, L2, or L3 controller terminals or to any other source of voltage. To do so will cause controller damage. Should it become necessary to bypass a controller not equipped with an iso-bypass option, the customer connections to the controller T1, T2, and T3 terminals must be disconnected to prevent back feeding the controller.

**CAUTION**

**DO NOT CONNECT INPUT POWER LEADS TO THE CONTROLLER OUTPUT TERMINALS (T1, T2, T3). DOING SO WILL DAMAGE THE CONTROLLER AND VOID THE WARRANTY.**

If a customer supplied isolating device is installed between the controller output and the motor (e.g. isolation contactor), the isolating device must not be switched to the open position and then back to the closed position, unless sufficient time is allowed for the motor open-circuit voltage to decay to less than 10% of the motor nameplate rated voltage. Re-connecting the motor to the operating controller without allowing the motor terminal voltage to decay may cause controller damage. When multiple motors are operated from one controller, several critical requirements must be met to assure proper controller and motor operation.

1. Individual motor overload protection must be provided in accordance with the National Electrical Code or applicable local codes.

2. The total of the connected motor nameplate load currents, as seen by the controller, must not exceed the controller rated output current.
3. If one or more of the motors are to be connected or disconnected from the controller while the controller is operating, the following conditions *must be met*.
  - A) The motor isolating device must not allow reconnection of the motor to the controller without first allowing the motor open-circuit voltage to decay to less than 10% of the motor nameplate rated voltage.
  - B) The summation of the running currents of the connected motors and the locked rotor current of the motor(s) being reconnected to the controller must be less than 110% of controller rated output current.

**2.2.4 CONTROL WIRING**

If the OMEGAPAK controller does not have pilot devices mounted in the door cover, refer to Section 11.5 for wiring of remote control operators station. Refer to Figure 2.4 for data on maximum wire size.

NOTE: All remote manual speed potentiometers must be wired with insulated shielded cable. One end of the shield must be grounded at the controller per the wiring diagram. The other end must be insulated from ground and **unconnected**.

When wiring external control devices to the controller's sequencing circuitry the following guidelines should be considered:

**Pilot Devices** (push buttons, selector switches, relay contacts, etc.) — The maximum distance from the controller to an external pilot device is limited by the dc resistance of the wiring plus the remote device contact resistance and the leakage capacitance between the conductors. Wire size must be selected such that the maximum circuit resistance (wire plus remote contact) does not exceed 10.5 ohms. Higher resistance may result in failure to deliver sufficient voltage to pick up the controller sequencing relays. Maximum leakage capacitance of installed wire must not exceed 1.4 microfarads. Higher leakage capacitance may prevent the controller sequencing relays from dropping out.

**Solid State Contacts** — Many solid state control devices, such as programmable controllers, use solid state switches (Triacs) in the output stages. In addition to criteria stated above for resistance and leakage capacitance, the off state resistance must limit leakage current (with 24v applied) to not more than .5 ma.

**OMEGAPAK Controller Relays** — Some relays in the controller have extra contacts available for controlling the remote devices. These contacts are rated as described in Figure 2.3.

**FIGURE 2.3  
MAXIMUM ELECTRICAL  
RELAY CONTACT RATINGS**

Relay Designation	Contact Arrangement	Contact Current Rating	Contact Type	Maximum Initial Contact Resistance
DFR	DPDT	2A, at 28VDC, .5A, at 120VAC, resistive	Gold over Silver	100 million
RCR	DPDT	2A, at 28VDC, .5A, at 120VAC, resistive	Gold over Silver	100 million
DRR	DPDT	4A, at 30 VDC 4A, at 250VAC resistive	Silver Cadmium Oxide	50 million

NOTE: To avoid electrical noise problems and nuisance tripping of the adjustable frequency controller, all remote controlled inductive loads (relay coils, contactor coils, solenoids, etc.) must be transient suppressed.

**2.2.5 WIRING PRACTICE**

Good wiring practice requires that control circuit wiring be separated from all power (line) wiring and all load wiring to the motor have the maximum possible separation from this power (line) wiring (whether from the same controller or other controllers). This minimizes the possibility of electrical transients being electrostatically or electromagnetically coupled from the power (line and load) circuits into the control circuits or from the load circuits onto the power (line) circuits.

The following general wiring practice is recommended in addition to that already prescribed in National Electrical Code and applicable local electrical codes.

Controllers are intended to be wired using conduit. Metallic conduit is preferred. Control and power wiring should never be run in the same conduit. Metallic conduits carrying power wiring and metallic conduits

carrying low level control wiring should be separated by at least three inches. Non-metallic conduits or cable trays carrying power wiring and non-metallic conduits or cable trays carrying low level control wiring should be separated by at least twelve inches. If it is necessary to cross power and control wiring, the above spacing recommendations should be observed and conduits or trays should cross at right angles.

Refer to Section 11, Controller Drawings for

outline drawings which show recommended conduit entry areas.

All low level control wiring (start-stop circuits, manual speed potentiometer, etc.) may be run in the same conduit or tray. Remote mounted manual speed potentiometers must be wired using shielded cable. The shielded cable must be jacketed and the shield terminated only where shown on the connection diagram. Refer to Section 11, Controller Drawings for connection diagrams of remote pilot devices.

FIGURE 2.5

LUG & MAXIMUM WIRE SIZE TABLE

Application	Number Conductors	Wire Size		Tightening Torque	
Control Circuit (Main Control Board)	1	N/A	12AWG	7 lb-in	
	or 1	N/A	14AWG		
	or 2	N/A	16AWG		
	or 3	N/A	18AWG		
	or 5	N/A	20AWG		
INCOMING POWER					
1-25 HP	1	18AWG	4AWG	34 lb-in	
30-50 HP	1	12AWG	1/0AWG	47 lb-in	
Fusible Disconnect <sup>①</sup> Switch	1	14AWG	6AWG	35 lb-in 40 lb-in	
		14AWG 8AWG	10AWG 6AWG		
Circuit Breaker <sup>①</sup>	1	14AWG	4AWG	35 lb-in	
Main Lugs <sup>②</sup>	1	14AWG	2/0AWG	120 lb-in 40 lb-in 35 lb-in	
		6AWG	2/0AWG		
		8AWG 14AWG	10AWG		
Isolation and Isolation/Bypass Contactors (Load Connections)					
	1	14AWG	8AWG	20 lb-in	
	1	14AWG	4AWG	50 lb-in	
30-50 HP	1	14AWG	1/0 AWG	100 lb-in	
Output Power (Motor)	1	18AWG	4AWG	34 lb-in	
Ground					
	1000 Controller	1	18AWG	4AWG	34 lb-in
	2000 Controller	1	8AWG	2AWG	60 lb-in
3000 Controller	N/A	Ground Bus		N/A	

① Optional with 2000 controllers. High flexibility connectors should be avoided due to the increased possibility of a poor connection.

② Used only on Type VT 2000 controllers with optional bypass contactors.

**3.0 APPLICATION DATA**

**3.1 BASIC CONTROLLER**

**3.1.1 INPUT**

Voltage 200/230/460vac +10%,  
-5%

Frequency 50/60 Hertz

Maximum Continuous Input Current -  
See Section 2.0, Figure 2.1

Three Phase Phase Rotation Insens-  
Only sitive

Displacement .95 lagging @ rated load  
Power Factor

Control Power 24vac and 24vdc

Pilot Lights 24vac (Full Voltage Only)

**3.1.2 OUTPUT**

Frequency 3 to 60 Hertz

Voltage 0 to 200vac, 0 to 230vac,  
0 to 460vac, three phase

Waveform Sine coded PWM (Pulse  
Width Modulated)

Maximum Continuous Output Rated  
Current - See Section 2.0, Figure 2.1

Short Time 120% of maximum con-  
Overload tinuous output rated  
current for 60 seconds.

**OUTPUT SIGNALS**

Current 0 to 5vdc proportional to  
output current, 5vdc  
equals 150% of maxi-  
mum continuous output  
current.

Voltage 0 to 5vdc proportional to  
the fundamental output  
voltage, 4vdc equals 460  
output voltage.

Frequency 0 to 5vdc proportional to  
output frequency/motor  
speed, 2.5vdc equals  
selected Hertz/motor  
base (rated) speed.

Run Command One normally open con-  
Relay (RCR) tact rated 2.0 amps @  
28vdc or 0.5 amps @ 120  
vac resistive.

Drive Run One Form C contact  
Relay (DRR) rated 4.0 amps @ 30vdc  
or 250 vac resistive.

Drive Fail One Form C contact  
Relay (DFR) rated 2.0 amps @ 28vdc  
or 0.5 amps @ 120vac  
resistive.

**3.1.3 PERFORMANCE**

**Controller Linearity (Percent of FBase)**

FBase = 60 Hz  
±.25 Typ.

Auto or Hand Input  
Frequency Stability At 25 °C Ambient ±.55 Hz Max.  
Frequency Shift With Ambient Temperatures:  
Hand Input ±.01 Hz/°C Typ., ±.015 Hz/°C max.

Current Limit Adjustable 75% to  
120% of maximum con-  
tinuous output rated  
current.

**3.1.4 ENVIRONMENTAL CONDITIONS**

Storage -17 °C to 60 °C (0 °F to  
Temperature 140 °F)

Operating Enclosed 0 ° to 40 °C  
(Ambient) (32 °F to 104 °F) Open  
Temperature 0 °C to 40 °C (32 °F to  
104 °F)

Altitude To 1,000 meters (3,300  
feet) w/o derating

Relative To 95% maximum  
Humidity non-condensing

**3.1.5 ADJUSTMENTS**

Current Limit Adjustable 75-120% of  
maximum continuous  
output rated current.

Voltage Boost Adjustable 100% to  
400% of nominal Volts/  
Hz ratio in constant  
Volts/Hz range. This  
boost is fully effective at  
3 Hz and tapers to zero  
boost at 20 Hertz. (60%  
to 200% for variable  
Volts/Hertz range)

Output Maximum 60 Hertz  
Frequency output.  
Range

Maximum Frequency	Adjustable 40 Hertz to 60 Hertz (33 Hertz to 50 Hertz in 50 Hertz range).	Overload	Adjustable 0% to 100% of maximum continuous output rated current.
Minimum Frequency	Adjustable 3 Hertz to 54 Hertz (3 Hertz to 45 Hertz in 50 Hertz range).	Overfrequency	Non-adjustable clamp limits output frequency to not more than 75 Hertz.
Acceleration/Deceleration Time Range	Range selection from 6 seconds to 75 seconds for 60 Hertz maximum operating frequency.	Overvoltage	Protects the controller against excessive dc bus voltage. Trips at 900vdc for 460vac systems or 450vdc for 200/230vac systems.
Acceleration Time	Adjustable over selected range.	Undervoltage	Trips at 87.5% of rated input voltage. Automatically resets at 95% of rated input voltage.
Deceleration Time	Adjustable over selected range.	Shoot-Through	Protects the controller against dc bus short circuits caused by missequencing of the inverter GTO switches. Trips at 100vdc for 460vac systems or 50vdc for 200/230vac systems.
Overload Threshold	Adjustable 0% to 115% of maximum continuous output rated current.	Input Fuses	Three current limiting fuses provide coordinated protection of the controller power circuit for fault withstand capability of 65,000 RMS symmetrical amperes.
Input Voltage	200vac, 230vac or 460vac operation.	Bus Undervoltage	Protects the controller against dc bus undervoltage due to loss of a phase. Trips at 400vdc for 460 vac systems or 200 vdc for 200/230vac systems.
Input Frequency	The controller is factory set to operate from 60 Hertz power. Adjustable for operation from a 50 Hertz power source.		
One or Two Fault Lockout	For OV faults only, the controller is factory set for lock-out (manual reset) after first protective circuit trip. Selectable automatic reset after first trip and lockout after second trip within 28 seconds of the first.		

**3.1.6 PROTECTION**

Instantaneous Overcurrent Trip	Non-adjustable trip setting of 130% of peak maximum continuous output rated current.
Ground Fault	Non-adjustable trip setting of 27 amperes peak. Trips in 6 microseconds when current settings are exceeded.
Full Time Current Limit	Adjustable 75% to 120% of maximum continuous output rated current.
Over-temperature	Thermostat mounted on heatsink.

**3.1.7 DIAGNOSTIC AND STATUS INDICATORS**

Light Emitting Diodes (LEDs) and a neon light are provided for the following:

- Bus Undervoltage (BUV)
- Undervoltage (UV)
- Overvoltage (OV)
- Ground Fault (GF)
- Instantaneous Overcurrent (IOC)
- Shoot Through (ST)
- Overtemperature (OT)
- Overload (OLD)

Overload Timer (OLT)  
 Motor Current Limit (MCL)  
 Power Up Delay (PUD)  
 Drive Enabled (DE)  
 Power (PWR)  
 NOTE: A detailed description of the diagnostic and status indicators is located in Section 7.0

Manual Speed Potentiometer Class 9001, Type K2107

**MOD F16**

Drive Fail Pilot Light Class 9001, Type KT35  
 Class 9001, Type KN399 (DRIVE FAIL)

**MOD P16**

Power On Pilot Light Class 9001, Type KP35  
 Class 9001 KN338 Legend Plate

**MOD R16**

Run Pilot Light Class 9001, Type KT35  
 Class 9001, Type KN324 Legend Plate

① Refer to wiring diagram section of this service bulletin for terminal connections.

**3.2 OPTIONS**

There are a number of factory and/or field installed options for the Class 8804 OMEGAPAK controller. To determine which options (if any) were factory installed, refer to the controller nameplate for the MOD alphanumeric listing.

**3.2.1 CONTROLLER MOUNTED PILOT DEVICES①**

**MOD A10**

Hand-Auto-Selector Switch Class 9001, Type KS11B-H2  
 Class 9001, Type KN 340 Legend Plate

Start Push Button Class 9001, Type KR1B-H13  
 Class 9001, Type KN301 Legend Plate

Stop Push Button Class 9001, Type KR1R-H13  
 Class 9001, Type KN302 Legend Plate

Manual Speed Potentiometer Class 9001, Type K2107

**MOD H10**

Hand-Off-Auto Selector Switch Class 9001, Type KS43B-H2  
 Class 9001, Type KN-360 Legend Plate

Manual Speed Potentiometer Class 9001, Type K2107

**MOD S10**

Start Push Button Class 9001, Type KR1B-H13  
 Stop Push Button Class 9001, Type KR1R-H13  
 Class 9001, Type KN-302 Legend Plate

**3.2.2 OUTPUT ISOLATION CONTACTOR**

**MOD C13**

Square D Class 8502 Type S Contactor properly sized for controller maximum continuous output current. Includes a 200/230/460 - 120 volt control power transformer with 2 primary and one secondary fuse. Not available in OMEGAPAK 1000 controllers.

**3.2.3 ISOLATION & BYPASS CONTACTORS**

**MOD E13**

Includes isolation contactor mechanically and electrically interlocked with a full voltage combination starter to provide emergency full speed operation in the event the controller is out of service, a transfer delay timer and an AFC-Bypass Selector Switch. NOTE: Combination starter does **not include** thermal overload heaters. Not available in OMEGAPAK 1000 controllers.

**3.2.4 CIRCUIT BREAKER DISCONNECT**

**MOD C12**

MAG-GARD®, magnetic trip circuit breaker with external, door-interlocked operator. Not available in OMEGAPAK 1000 controllers.

**3.2.5 FUSIBLE DISCONNECT SWITCH****MOD D12**

Square D visible blade disconnect switch with fuse clips, without fuses with external, door-interlocked operator. Not available in OMEGAPAK 1000 controllers.

**3.2.6 METERS**

The meters described below are available in kit form for remote mounting. Factory installed meters are not available in 1000 controllers.

**MOD A14** (Kit Class 8804, Type AM-1)

Analog Speed Meter - 3-1/2 inch meter with indicating scale of 0-100% speed. This meter is connected to the Main Control Board. A 0-5 vdc signal is used to drive this meter.

**MOD D14** (Kit Class 8804, Type DM-1) ①

Digital Speed Meter - 3-1/2 inch meter selectable to indicate 0-100% speed or 0-1999 RPM (Maximum RPM indication is 1999). This meter is connected to the same terminal points as the analog meter (MOD A14) described above.

**MOD T15**

Elapsed Time Meter - 3-1/2 inch meter with indicating scale of 99999.9 hours maximum. This meter is connected to the Main Control Board (refer to wiring diagram section of this Service Bulletin).

**MOD V15** (Kit Class 8804, Type AM-2)

Analog Voltmeter - 3-1/2 inch meter with indicating scale of 0-125% of rated output voltage. This meter is connected to the main control board. A 0-5 vdc signal drives this meter.

**MOD F15** (Kit Class 8804, Type DM-1) ①

Digital Voltmeter - 3-1/2 inch meter adjustable to read 0-100.0% of rated output voltage. This meter is driven by the same 0-5 vdc signal as the analog voltmeter.

**MOD A15** (Kit Class 8804, Type AM-3)

Analog Ammeter - 3-1/2 inch meter with indicating scale to read 0-150% of rated controller output current. This meter is connected to the main control board. A 0-5 vdc signal drives this meter.


**MOD G15** (Kit Class 8804, Type DM-1) ①

Digital Ammeter - 3-1/2 inch meter adjustable to read 0-150.0% of rated controller output current. This meter is driven by the same 0-5 vdc signal as the analog ammeter.

① The Class 8804 Type DM-1 meter can be field adjusted to display speed, voltage or current.

4.1 OMEGAPAK 1000 CONTROLLER

1-20 HP @ 460V







4.0 CONTROLLER COMPONENT LOCATION

4.1 OMEGAPAK 1000 CONTROLLER

25 HP @ 460V




4.1 OMEGAPAK 1000 CONTROLLER  
25 HP @ 460V




4.1 OMEGAPAK 1000 CONTROLLER

30-40 HP @ 460V




**4.1 OMEGAPAK 1000 CONTROLLER**


30-40 HP @ 460V




4.1 OMEGAPAK 1000 CONTROLLER  
50 HP @ 460V



4.1 OMEGAPAK 1000 CONTROLLER  
50 HP @ 460V




4.2 OMEGAPAK 2000 CONTROLLER  
25 HP @ 460V




**4.2 OMEGAPAK 2000 CONTROLLER**

**25 HP @ 460V**






4.2 OMEGAPAK 2000 CONTROLLER  
50 HP @ 460V



**4.2 OMEGAPAK 2000 CONTROLLER**  
50 HP @ 460V



**5.0 INITIAL START-UP PROCEDURE**

**5.1 INITIAL START-UP PROCEDURE**

The OMEGAPAK controller has been tested at the factory and should require only minor adjustments to complete the field installation. This start-up procedure should be followed step by step. In case of difficulty refer to the TROUBLESHOOTING section of this service bulletin.

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**BEFORE SERVICING, TURN OFF POWER**  
**SUPPLY(S) TO THIS EQUIPMENT. WAIT FIVE**  
**MINUTES. MEASURE CAPACITOR VOLTAGES**  
**TO VERIFY THEY ARE ZERO. DO NOT SHORT**  
**ACROSS CAPACITORS WITH VOLTAGE**  
**PRESENT.**

**WITH ALL INCOMING POWER REMOVED,** make the following equipment settings and adjustment:

- A. Verify that all equipment disconnect means are open.
- B. Connect the Control Power Transformer primary taps as illustrated in Section 6.0, Figure 6.1, for the system input voltage. Refer to Section 4.0, OMEGAPAK Controller Photo for location of the control power transformers.
- C. Connect the Control Power Transformer primary taps for the Isolation Contactor or Isolation and By-Pass Contactor (if used) as illustrated in Section 6.0, Figure 6.2, for the system input voltage. Refer to Section 4.0, OMEGAPAK Controller Photos for location of the control power transformer.
- D. Temporarily place a jumper from TB1-89 to TB1-91.
- E. Temporarily disconnect and isolate the analog follower input signal wiring from TB1.
- F. Set selection switches SW1 through SW8 on the main control board as required. See Section 6.0, Figure 6.3. Refer to Section 8.0, Selection Switch Placement chart, for location of switch.

G. Configure the snip-out resistors on the main control board as required. See Section 6.0, Figure 6.4. Refer to Section 8.0, Snip-Out Resistor Placement chart, for location of resistors.

H. The following adjustments on the main control board were factory set as follows. Refer to Section 8.0, Potentiometer Placement chart, for location of potentiometers. *Do not adjust any potentiometers unless directed in the start-up procedure.*

+10VDC SUPPLY ADJUST (P1)*	+10vdc
DECELERATION TIME (P2)	Maximum (full clockwise)
ACCELERATION TIME (P3)	Maximum (full clockwise)
MAXIMUM SPEED (P4)	60 Hz Output with nominal speed ref.
HAND MINIMUM SPEED (P5)	Minimum 3 Hz (full counterclockwise)
GAIN ADJUST (P6)*	Optimized for controller
MOTOR CURRENT LIMIT (P7)	Maximum (full clockwise)
OVERLOAD THRESHOLD (P8)	Maximum (full clockwise)
FREQUENCY CLOCK TRIGGER (P9)	Optimized for controller
VOLTAGE BOOST (P10)	Minimum (full counterclockwise)
REFERENCE CLOCK TRIGGER (P11)*	Optimized for controller
OUTPUT CLOCK TRIGGER (P12)*	Optimized for controller
VOLTS/HERTZ TRIM (P13)*	Optimized for standard motor

\* Designates potentiometers that have been factory sealed. **DO NOT ADJUST!**

- I. Set the HAND-OFF-AUTO Switch to OFF⓪.
- J. Set the MANUAL SPEED adjustment potentiometer to minimum (full counterclockwise).
- K. Confirm that the Isolation-Bypass Unit (if used) AFC-Off-Line selector switch is in the OFF position.
- L. Check wiring of input power, panel ground, motor, manual speed potentiometer (if remote) and Hand-Off-Auto⓪ circuit con-

nections, (if remote). Refer to Section 11.0 for the controller connection diagram and wiring diagram for remote control station.

- M. Verify that the incoming line voltage at the line side of the disconnecting means is within +10% to -5% of the controller nameplate input voltage.

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**CONTROLLER PANEL MUST BE PROPERLY**  
**GROUNDING BEFORE APPLYING POWER.**  
**CLOSE AND SECURE ENCLOSURE DOOR**  
**BEFORE APPLYING POWER.**

**WITH INCOMING POWER PRESENT**

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**CERTAIN ADJUSTMENTS AND TEST PRO-**  
**CEDURES REQUIRE THAT POWER BE AP-**  
**PLIED TO THIS CONTROLLER. WHEN WORK-**  
**ING WITH ENERGIZED EQUIPMENT, EX-**  
**TREME CAUTION MUST BE EXERCISED AS**  
**HAZARDOUS VOLTAGES EXIST. THE**  
**ENCLOSURE DOOR MUST BE CLOSED AND**  
**SECURED WHILE TURNING ON POWER,**  
**OR STARTING AND STOPPING THIS CON-**  
**TROLLER.**

- N. Close and secure the enclosure door. Close the equipment disconnect means. The Power On lamp (if used) should light. Other lamps (if used) may be tested by pushing their lenses (if push to test lamps are used).
- O. Verify that **only** the following lamps are lighted: (LED 1) PWR on the Main Control Board, and Neon Lamp (IL1) on the Power Interface Board. Refer to Section 8.0, LED Placement chart, for location of LED's and Section 4.0 Controller Photos for location of Neon lamp.
- P. If an Isolation-Bypass unit is not used proceed to Step T.
- Q. If the Isolation-Bypass unit is used, turn the AFC-Off-Line selector switch to the Line position. If necessary, adjust the disconnect means trip setting to the lowest value that will not result in

nuisance tripping. The motor should accelerate to full speed. Check the motor rotation. If it is incorrect, stop the drive by turning the AFC-Off-Line selector switch to Off. **REMOVE ALL POWER!**

- R. Correct the phase sequence of the motor by reversing motor leads T1 and T2 at the output of the Isolation-Bypass unit. Reapply power.
- S. Turn the Isolation-Bypass unit (if used) AFC-Off-Line selector switch to AFC.
- T. Close and secure the enclosure door. Turn the Hand-Off-Auto<sup>Ⓢ</sup> Selector Switch to Hand. Slowly turn the Manual Speed adjustment potentiometer clockwise to accelerate the drive motor. Check the direction of motor rotation. If correct, proceed to Step Z. If incorrect, stop drive. **REMOVE ALL POWER!**

**DANGER**  
**HAZARD OF ELECTRICAL SHOCK OR BURN**  
**BEFORE SERVICING, TURN OFF POWER**  
**SUPPLY(S) TO THIS EQUIPMENT. WAIT FIVE**  
**MINUTES. MEASURE CAPACITOR VOLTAGES**  
**TO VERIFY THAT THEY ARE ZERO. DO NOT**  
**SHORT ACROSS CAPACITORS WITH**  
**VOLTAGE PRESENT.**

- U. Correct the direction of motor rotation by one of the following methods:
1. If Isolation-Bypass is not used, reverse any two leads connected to output terminals T1, T2, T3.
  2. Remove Snip-Out Resistor R186. Refer to Section 8.0, Snip-Out Resistor Placement Chart, for location of resistor.
- V. Reset the Manual Speed adjustment potentiometer setting to minimum speed (full counterclockwise). Close and secure the enclosure door then, reapply power and restart the controller.
- W. Slowly increase the Manual Speed adjustment potentiometer setting to maximum (full clockwise). The motor speed should follow. If the motor will not accelerate or an IOC trip occurs during acceleration, refer to Section 6.0, Controller Adjustment, for setting of the Voltage Boost Potentiometer (P10).

- X. Check the maximum motor speed. Adjust the Maximum Speed Potentiometer (P4) on the main control board to obtain motor rated speed.
- Y. Return the Manual Speed adjustment potentiometer to minimum setting (full counterclockwise). The motor speed should follow.
- Z. Slowly adjust the Hand Minimum Speed potentiometer (P5) on the main control board to obtain the desired minimum speed.
- AA. Using the Manual Speed adjustment potentiometer adjust the motor speed for the point of maximum motor current. (This must not exceed the motor or controller nameplate current.) Slowly turn the Overload Threshold Adjust Potentiometer (P8) on the main control board counterclockwise until the Overload Timer (LED 3) OLT lights. Now, slowly turn P8 clockwise until the Overload Timer (LED 3) OLT just extinguishes. Then turn P8 an additional 5 degrees clockwise rotation.

**CAUTION**

**THIS CONTROLLER DOES NOT PROVIDE OVERTEMPERATURE PROTECTION FOR THE MOTOR AT ALL SPEEDS OR LOADING CONDITIONS. A MOTOR THERMAL SENSOR IS RECOMMENDED.**

- BB. The Acceleration Time (P3) and Deceleration Time (P2) Potentiometers on the main control board may be adjusted to suit individual applications. If an overvoltage trip occurs during deceleration, increase the deceleration time setting. If OV tripping persists, refer to Section 6.1.5.
- BB1. If a Hand-Off-Auto Switch is supplied, proceed to Step CC, otherwise proceed to EE.
- CC. Turn the Hand-Off-AutoⓈ switch to Auto.
- CCA. This step sets the signal level of analog follower inputs. For this application, the supply must be connected as

shown in Figure 5.2.A. The controller as shipped will accept 0-10vdc or 4-20 mdc for automatic speed control. If operation from a 4-20 ma signal is required, a jumper must be installed from Main Control Board terminal TB1-11 to TB1-71. Refer to Section 11, Drawing 11.7.3. This is shown in Figure 5.2.B.

- DD. Turn the Hand-Off-AutoⓈ selector switch to Off.

EE. REMOVE ALL POWER!

**DANGER**

**HAZARD OF ELECTRICAL SHOCK OR BURN BEFORE SERVICING, TURN OFF POWER SUPPLY(S) TO THIS EQUIPMENT. WAIT 5 MINUTES. MEASURE CAPACITOR VOLTAGES TO VERIFY THAT THEY ARE ZERO. DO NOT SHORT ACROSS CAPACITORS WITH VOLTAGE PRESENT.**

- FF. Remove the jumper from TB1-89 to TB1-91 installation in Step D. Reconnect any wires removed in Step E.
- KK. This completes the initial start-up and adjustment procedure. The controller is now set for most applications. If your application requires different operational characteristics, refer to Section 6.0, Controller Adjustment Description, in this service bulletin.

**Abnormal Operation**

Refer to Section 7.0, Diagnostic Indicating Lights, if any of the following LED's on the Main Control Board are illuminated.

- A. Undervoltage (UV)
- B. Overvoltage (OV)
- C. Shoot Through (ST)
- D. Ground Fault (GF)
- E. Instantaneous overcurrent (IOC)
- F. Overload (OLD)
- G. Overtemperature (OT)
- H. Bus Undervoltage (BUV)

- Ⓢ The Hand-Off-Auto selector switch may not always be used. Refer to Section 11.0, for other control configurations, either controller mounted or remote mounted.

FIGURE 5.2.A





FIGURE 5.2.B  
4-20MA DC INPUT



**6.0 CONTROLLER ADJUSTMENTS**

A number of adjustments have been provided in the OMEGAPAK controller for modifying the controller operating characteristics. These adjustments include Printed Wiring Board mounted Selection Switches, Snip-Out Resistors and Potentiometers. If the controller contains optional equipment there may be adjustments associated with these too. Each adjustment is described in the following paragraphs.

**CAUTION**

**DO NOT CHANGE THE POSITION OF ANY PRINTED WIRING BOARD SWITCH OR REMOVE ANY PRINTED WIRING BOARD WITH THE DRIVE RUNNING. TO DO SO MAY CAUSE AN EQUIPMENT MALFUNCTION.**

voltage, motor voltage, and motor base frequency as illustrated in Figure 6.3. (Refer to Section 8.0, selection switch placement chart, main control board, for selection switch location).

FIGURE 6.1 (A)

CONTROL TRANSFORMER CONNECTION ELECTRONICS CONTROL POWER (T1)		
SYSTEM INPUT VOLTAGE	PRIMARY TAPS	JUMPER CONNECTIONS
200	H1, H5	H1 TO H4, H2 TO H5
230	H1, H6	H1 TO H4, H3 TO H6
460	H1, H6	H3 TO H4

**6.1 MAIN CONTROL BOARD ADJUSTMENTS**

The adjustments on the main control board are:


- INPUT VOLTAGE SELECTION
- INPUT FREQUENCY SELECTION
- CONTROLLER FAULT LOCKOUT SELECTION
- POTENTIOMETER ADJUSTMENTS

**6.1.1 INPUT VOLTAGE SELECTION**

The controller is factory set to operate from 460vac. To operate the OMEGAPAK controller from 200vac or 230vac, the control power transformers jumper connections and main control board selection switches must be repositioned. If optional isolation or isolation and by-pass contactor is used, there are wiring jumper changes necessary to operate from 200vac or 230vac. The procedure is as follows:


1. Reconnect the control power transformers jumper connections for the desired system input voltage as illustrated in Figure 6.1. (Refer to Section 4.0, Controller Photos, for control power transformer locations).
2. Set the selection switches SW1, SW3, SW6, SW7, and SW8 on the main control board for the desired system input voltage

FIGURE 6.1 (B)



TERMINAL & JUMPER LOCATIONS  
460V OPERATION

FIGURE 6.1 (C)




CONNECTION DIAGRAM  
460V OPERATION

FIGURE 6.2 (A)


CONTROL TRANSFORMER CONNECTION OPTIONAL ISOLATION OR ISOLATION/BYPASS CONTACTORS (T1)			
SYSTEM INPUT VOLTAGE	PRIMARY TAPS	SECONDARY TAPS	JUMPER CONNECTIONS
200	H1, H4	X1, X3	H1 TO H3, H2 TO H4
230	H1, H4	X1, X2	H1 TO H3, H2 TO H4
460	H1, H4	X1, X2	H2 TO H3

FIGURE 6.2 (B)



TERMINAL AND JUMPER LOCATIONS  
460V OPERATION

FIGURE 6.2 (C)



CONNECTION DIAGRAM  
460V OPERATION

3. If optional isolation or isolation and bypass contactors are used with the OMEGAPAK 2000 controllers, their control power transformer jumper connections must be reconnected to operate from 200vac or 230vac as illustrated in Figure 6.2. (Refer to Section 4.0, OMEGAPAK Controller Photos, for control power transformer location.)

6.1.2 INPUT FREQUENCY SELECTION

The controller is factory set to operate from 60 Hertz power. To operate the controller from 50 Hertz power, one (1) Main Control Board Snip-Out Resistors (R164) must be removed as illustrated in Figure 6.4. (Refer to Section 8.0, Snip-Out Resistor Placement chart, Main Control Board, for snip-out resistor location).

6.1.3 CONTROLLER FAULT LOCKOUT SELECTION

The controller is factory set to Lockout, requiring manual reset, on the first fault detected. Controller faults that will cause lockout are:

- Overvoltage (OV)
- Shoot Through (ST)
- Ground Fault (GF)
- Overload (OLD)
- Instantaneous Overcurrent (IOC)
- Overtemperature (OT)
- Bus Undervoltage (BUV)

If first fault lockout is not desired, the controller can be set up for second fault lockout. When the controller is set up for second fault lockout operation, the drive will stop for 7 seconds, or the duration of the fault (whichever is longer), upon the first fault then restart automatically if two-wire control is used. If a second fault occurs within 28 seconds after the first fault the drive will stop and lockout.

To adjust the controller for two fault operation, one (1) Main Control Board Snip-Out Resistor (R144) must be removed as illustrated in Figure 6.4. (Refer to Section 8.0, Snip-Out Resistor Placement chart, Main Control Board, for snip-out resistor location).

NOTE: All controller faults can be manually reset by depressing an external Reset Button connected between TB1-33 and TB1-22 on the main control board (see



component placement chart for terminal locations) or by interrupting power to the controller input.

An undervoltage (UV) trip condition will stop the drive but will not cause a controller lockout. After the undervoltage (UV) fault subsides the drive will immediately restart on two wire control systems. Systems with three wire control will require a manual restart.

**6.1.4 CONSTANT OR VARIABLE VOLTS/HERTZ SELECTION**

The controller is factory set for constant volts/HZ operation. To select a variable volts/HZ operation, Main Control Board Snipout Resistors (R170 and R180) must be removed. Removing the snipout resistors indicated will result in a reduced volts/Hertz ratio at reduced frequencies. The major effect is reduced motor noise; however, a slight savings of energy may also be realized.

Removal is optional for variable torque loads; however, the resistors **must not** be

removed if the load requires high break-away torque. Figure 6.5 graphically illustrates the effect of the resistors.

NOTE: Variable Voltz/Hz mode will require adjustment of the Voltage Boost Potentiometer (PIO). Refer to Section 6.1.6 potentiometer adjustments for adjustment procedure.

**6.1.5 CONTROLLED/UNCONTROLLED STOP SELECTION**

The controller is set for a controlled stop with SW2 closed. With the controlled stop selected, the motor will decelerate at the ramp setting when a stop is requested. With SW2 open, the uncontrolled stop is selected. The motor will now coast to a stop when a stop is requested. However, the motor will still decelerate at the ramp rate when the speed reference is reduced; regardless of SW2 setting. The uncontrolled stop may be selected when the power regenerated from a decelerating load is great enough to trip the controller on overvoltage even at the maximum acceptable deceleration ramp setting.


**FIGURE 6.3  
MAIN CONTROL BOARD DIP SWITCH SETTINGS**

Switch	Function					
SW1	Controller Input/Motor Nameplate (Base) Voltage Select					
	Input (V)	200	230	230	460	460 <sup>①</sup>
	Base (V)	200	200	230	400	460 <sup>①</sup>
SW3	X	X	X	O	O	O*
SW6	X	X	O	O	O	O*
SW7	O	O	O	X	X	X*
SW8	Nameplate (Base) Frequency Select <sup>②</sup>					
	60 Hertz X*			50 Hertz O		
SW2	Controlled/Uncontrolled Stop Selection					
	Motor Will Decelerate To A Stop On Deceleration Ramp Setting X*			Motor Will Coast To A Stop O		
SW4 SW5	NOT USED					

① This switch setting also applies to 380 volts input and a 380 V motor. It is necessary to select 50 Hertz operation on SW8 to get the correct volts/Hertz relationship and adjust potentiometer P4 maximum speed (MSD) per section 6.1.6 to achieve a base frequency of 50 Hertz.

② Operation from a 50 Hertz supply also requires removal of snip-out resistors per Figure 6.4.

Typical Printed Wiring Board Switch




X = Closed Switch (ON)  
O = Open Switch (OFF)  
\* = Factory Setting

FIGURE 6.4  
MAIN CONTROL BOARD SNIP-OUT RESISTORS ① ②

Snip-Out Resistor	Function	Condition
R164	50 Hz or 60 Hz Operation ③	Installed: 60 Hz operation Removed: 50 Hz operation
R144	One or two fault lockout — all faults except UV	Installed: Drive will lockout upon one fault. Removed: Drive will stop for 7 sec. upon 1st fault and will lockout upon 2nd fault occurring 28 sec. after 1st fault.
R180 R170	Constant or variable V/Hz (see Figure 6.5)	Installed: Constant V/Hz ratio maintained permitting constant torque at reduced speed. Removed: Reduced V/Hz ratio at reduced output frequency for variable torque load.
R186	Reverse Rotation	Installed: Forward Rotation Removed: Reverse Rotation.

- ① Controllers are shipped with all snip-out components installed.
- ② If a component is to be removed, it is suggested that one lead be snipped and required operation confirmed before completely removing the component.
- ③ Switch SW8 on the Main Board must also be positioned per Figure 6.3 if a 50 Hz base frequency is also desired.

FIGURE 6.5



VOLTS/HZ VS. OUTPUT FREQUENCY (THEORETICAL)  
(WITHOUT VOLTAGE BOOST)

### 6.1.6 POTENTIOMETER ADJUSTMENTS

The potentiometer adjustments were factory set as described in the initial start-up procedure. Certain potentiometers are not expected to ever require adjustment. These have been factory sealed.

If further adjustments are necessary, adjust potentiometers one at a time in the following order.

P1- Positive 10V (+ 10V) — This potentiometer allows adjustment of the +10 volts regulated power supply. Potentiometer (P1) is factory adjusted and sealed. **This potentiometer should not be adjusted in the field.**

P2- Deceleration Time (DEC) — This potentiometer controls the amount of time for the output frequency to decrease from 60 Hertz to 3 Hertz. The Deceleration Time (DEC) potentiometer operates in the same manner as the Acceleration Time (ACC) potentiometer. This potentiometer is factory set for 75 second deceleration time.

With the motor running at full speed, stop the motor and observe the length of time that it takes to decelerate to zero speed. Clockwise rotation of the Deceleration Time (DEC) potentiometer increases deceleration time.

If a high inertia load is present: Deceleration time set too fast could cause an overvoltage trip. If this occurs increase the deceleration time setting.

P3- Acceleration Time (ACC) — The potentiometer controls the amount of time for the output frequency to increase from 3 Hertz to 60 Hertz. The time is adjustable from 6 to 75 seconds. This potentiometer is factory set for 75 second acceleration time. With the motor stopped, turn the Manual Speed potentiometer to the maximum setting. Start the motor and observe the length of time that it takes to accelerate to full speed. Clockwise rotation of the Acceleration Time (ACC) potentiometer increases acceleration ramp time.

P4- Maximum Speed (MSD) — This potentiometer is used to control the controller output frequency when the Manual Speed potentiometer (controller mounted or remote mounted) is set at its maximum level (full clockwise). This potentiometer is factory set so that the output frequency will be 60 Hertz when the Manual Speed potentiometer is set full clockwise. The Maximum Speed (MSD) potentiometer has an adjustment range of 40 Hertz to 60 Hertz (33 Hertz to 50 Hertz if a 50 Hertz Base Frequency is selected per Figure 6.3 and 6.4).

The Maximum Speed (MSD) potentiometer must be adjusted if a maximum frequency other than 60 Hertz is required. Clockwise rotation increases output frequency.

P5- Hand Minimum Reference (HMR) — This potentiometer controls the minimum speed the motor will run, when the Manual Speed potentiometer (controller mounted or remote mounted) is set at minimum level (full counterclockwise). This potentiometer is factory set to produce an output frequency of 3 Hertz when the Manual Speed potentiometer is set full counterclockwise. The Hand Minimum Reference (HMR) potentiometer has an adjustable range of 3 Hertz to 54 Hertz.

#### CAUTION

**THIS CONTROLLER DOES NOT PROVIDE OVER-TEMPERATURE PROTECTION FOR THE MOTOR AT ALL SPEEDS OR LOADING CONDITIONS. A MOTOR THERMAL SENSOR IS RECOMMENDED.**

The minimum speed is set by rotating the Manual Speed potentiometer to the minimum level (full counterclockwise) and adjusting the Hand Minimum Reference (HMR) clockwise for desired minimum motor speed.

P6- GAIN (GA) — Sets the gain in the current feedback circuit to compensate for component tolerances. This potentiometer is factory adjusted and sealed. **It must not be field adjusted. The warranty is voided if the seal is broken.**

- P7- Motor Current Limit (MCL) — This potentiometer limits the maximum motor running current in the range of 75-120% of the controller maximum output rated current. The Motor Current Limit (MCL) potentiometer is factory set full clockwise to allow maximum current to be delivered to the motor.

If less than 120% current limit setting is required for a particular application the potentiometer can be adjusted counterclockwise.

- P8- Overload Threshold (OLD) — This potentiometer is used to set the threshold at which the overload timer will be activated. The Overload Threshold (OLD) potentiometer is factory set full clockwise which corresponds to 115% of the controller output rated current.

If the motor current exceeds 115% of the controller output rated current, an overload timer will activate and the Overload Timer (LED 3) OLT will light. Should the current remain above the setpoint for 60 seconds, the drive will trip out. If the controller is to be used with a motor whose full load current is less than the controller output rated current, an adjustment will be required.

#### CAUTION

**THIS CONTROLLER DOES NOT PROVIDE OVER-TEMPERATURE PROTECTION FOR THE MOTOR AT ALL SPEEDS OR LOADING CONDITIONS. A MOTOR THERMAL SENSOR IS RECOMMENDED.**

All main control board potentiometer adjustments should be made before attempting to adjust the Overload Threshold (OLD) potentiometer. The adjustment procedure must be followed:

#### Adjustment Procedure

- A. Start the motor
- B. Adjust the Manual Speed potentiometer for the point of maximum motor current. (This must not ex-

ceed 100% of motor nameplate current or controller rated output current)

- C. Slowly turn the Overload Threshold (OLD) potentiometer counterclockwise until the Overload Timer (LED 3) OLT lights.
- D. Slowly turn the Overload Threshold (OLD) potentiometer until the Overload Timer (LED 3) OLT extinguishes.
- E. Turn Overload Threshold (OLD) potentiometer clockwise an additional 5 degrees.

- P9- Frequency Clock Trigger (FCT) — This potentiometer is used to improve the linearity of output frequency vs input speed reference. This potentiometer is factory adjusted and sealed. **This potentiometer should not be adjusted in the field.**

- P10- Voltage Boost (EB) — This potentiometer increases the Volts per Hertz (V/Hz) ratio at frequencies 20 Hertz and below. In high starting torque, rapid acceleration or reduced Volts/Hertz applications the V/Hz ratio must be increased at low frequencies to compensate for IR losses in the motor windings. This potentiometer is factory set for zero (0) voltage boost. If the motor accelerates normally, this potentiometer should not be adjusted.

If the motor will not accelerate normally or nuisance IOC trips are experienced during acceleration, this potentiometer must be adjusted.

Energize the controller with the motor loaded and adjust the Manual Speed potentiometer (controller mounted or remote mounted) to the maximum speed position. If the motor does not accelerate, or if nuisance tripping occurs, stop the controller and turn the Voltage Boost (EB) clockwise approximately 10 degrees. Repeat this procedure until the motor accelerates normally. Do not turn the potentiometer any further than necessary to accelerate the motor.

NOTE: If the VOLTAGE BOOST (EB) potentiometer is set too high, the controller will lock up in current limit and inhibit the acceleration ramp. If this condition occurs it will be necessary to reduce the setting of the Voltage Boost (EB) potentiometer until the motor will accelerate.

- P11- Reference Clock Trigger (RCT) — This potentiometer determines the maximum inverter switching frequency. This potentiometer is factory adjusted and sealed. **This potentiometer should not be adjusted in the field.**
- P12- Output Clock Trigger (OCT) — This potentiometer sets the interlock delay, which is the time between periods of conduction of GTO's in the same leg of the inverter. **This potentiometer should not be adjusted in the field.**
- P13- Volts/Hertz (VHZ) — This potentiometer allows trimming of the volts per Hertz ratio of the controller output. The Voltz/Hertz (P13) potentiometer is factory adjusted and sealed. **This potentiometer should not be adjusted in the field.**

## 6.2 METER ADJUSTMENTS

Analog or digital speed indicating meters can be furnished factory installed on OMEGAPAK 2000 controllers only or furnished in kit form for remote mounting.

### 6.2.1 Analog Speed indicating Meter (MOD A14) (Kit Class 8804, Type AM-1) (Scale 0-100%)


— A factory installed analog speed indicating meter is set to indicate 100% (full scale) at 60 Hertz output frequency. If the controller is to operate over the range of 0-60 Hertz no field adjustment will be necessary. A meter reading of 100% corresponds to 100% of motor rated speed.

### 6.2.2 Digital Speed Indicating Meter (MOD D14) (Kit Class 8804, Type DM-1) (Scale 0-199.9 or 0-1999)

— A factory installed digital speed indicating meter is factory set to indicate 100.0 at 60 Hertz output frequency. This corresponds to 100% of motor rated speed. If

the controller is to operate over the range of 0-60 Hertz and percent of motor rated speed is the desired indication, no adjustment is necessary.

FIGURE 6.10  
PRINTED WIRING BOARD  
FOR DIGITAL  
INDICATING METER



CONVERSION TO FREQUENCY READOUT — To change calibration of the speed meter to indicating **approximate** output frequency it is only necessary to adjust the Calibration Potentiometer (P1) on the rear of the meter. With the controller operating at maximum speed as factory set (60 Hertz output), adjust the meter calibration potentiometer to produce a meter reading of 60.0.

If the controller maximum speed has been changed from the factory set maximum speed, the meter can be calibrated using a dc voltmeter. Measure the voltage between terminals MTR (+) and COM (-) on the Printed Wiring Board (see Figure 6.10) and adjust the controller Manual Speed Adjust potentiometer until the voltmeter reads exactly 2.5vdc. This voltage corresponds to 60 Hertz output. Adjust the Meter Calibration potentiometer to read 60.0.

NOTE: The meter provides only a relative indication of output frequency.

CONVERSION TO RPM READOUT — The digital speed meter is capable of displaying RPM over the range of 0-1999 RPM. To convert the meter to RPM readout it is

necessary to clip out resistor R6 located on the Printed Wiring Board on the rear of the meter (See Figure 6.10). This disables the decimal point. The controller should then be operated at 60 Hertz and the motor speed measured with a tachometer. The Meter Calibration potentiometer located on the rear of the meter should be adjusted until the meter indication corresponds to the tachometer reading.

Alternate method — Measure the voltage between terminal MTR (+) and COM (–) on the Speed Indicating Meter Printed Wiring Board. Adjust the controller speed to produce a voltmeter reading of 2.5vdc. This corresponds to a controller operating frequency of 60 Hertz. Adjust the Meter Calibration potentiometer until the meter reads the motor rated speed as shown on the motor nameplate.

### 6.2.3 ANALOG VOLTMETER (MOD V15) (Kit Class 8804 Type AM-2) (Scale 0-125%)

Factory installed analog voltmeters are set to read 100% with 460 volts output from the controller. This meter operates from a 0-5 vdc signal from the controller. Meter output signals correspond to controller output voltages as follows:

- 4 vdc = 460V
- 2 vdc = 230V
- 1.74 vdc = 200V

If the controller is to be used on 230V or 200V systems, it will be necessary to recalibrate the meter. The meter can be calibrated by the following procedure:

1. Connect a D.C. Voltmeter between terminals TB1-26 (+) and TB1-31 (–) on the Main Control Board. Energize the controller and increase the output frequency until a reading of 4.0 vdc is obtained for 460V operation, 2.0 vdc is obtained for 230V operation or 1.74 vdc is obtained for 200V operation. This indicates the controller is operating at rated output voltage.
2. Adjust the potentiometer on the meter's printed wiring board, for 100% voltage output indication.
3. Remove the D.C. Voltmeter from the Main Control Board. The Voltmeter is now calibrated and should read all intermediate voltages accurately.

Note: Due to the complex, output waveform from the controller, attempts to measure the controller output terminal voltage will produce erroneous readings and is therefore not recommended.

### 6.2.4 DIGITAL VOLTMETER (MOD F15) (Kit Class 8804 Type DM-1) (Scale 0-100.0%)

Follow the procedure for adjusting the analog voltmeter described in Section 6.2.3.

### 6.2.5 ANALOG AMMETER (MOD A15) (Kit Class 8804 Type AM-3) (Scale 0-150%)

Factory installed analog ammeters are set to read 100% when the controller delivers rated output current as stamped on the controller nameplate. This meter operates from a 0-5 vdc signal from the controller (5 vdc = 150%) of rated output current. The meter can be calibrated by the following procedure:

1. Connect a D.C. Voltmeter between terminals TB1-30 (+) and TB1-31 (–) on the Main Control Board. Energize the controller, with a connected motor load, and increase the controller frequency until a reading of at least 1.0 vdc is obtained.
2. Calculate the percent controller rated output current using the following formula. Percent rated current =  $30 \times$  Measured voltage in Step 1.
3. Adjust the potentiometer on the meter's printed wiring board, for the percent rated current output indication as calculated in Step 2.
4. Remove the D.C. Voltmeter from the Main Control Board. The Ammeter is now calibrated and should read all the intermediate currents accurately.

### 6.2.6 DIGITAL AMMETER (MOD G15) (Kit Class 8804 Type DM-1) (Scale 0-150.0%)

Follow the procedure for adjusting the analog ammeter described in Section 6.2.5.

## 7.0 DIAGNOSTIC AND STATUS INDICATING LIGHTS

There are nineteen (19) diagnostic and status indicating, Light Emitting Diodes (LED's) & one Neon light in a basic controller. The LED's and Neon light are located on the following printed wiring boards:

Basic Controller:

- Main Control Board — Thirteen (13) LED's
- Gate Driver Board — One (1) LED on each board (there are a total of six (6) gate driver boards).
- Power Interface board — One (1) Neon Light

These LED's provide a visual indication of protective functions and circuit status. When diagnosing a controller operational problem the prospective LED will illuminate to indicate what protective function was activated. There are some LED's lighted when power is applied to the controller. The function of each indicator is described in the following 7.1 through 7.4 paragraphs. (Refer to Section 8.0, LED Placement chart, Main Control Board for location of LED's and Section 4.0, Controller Photo, for location of Neon Light.)

### 7.1 MAIN CONTROL BOARD LED'S

- PWR (LED 1) Power — Indicates when power is available for the control circuits. Should be illuminated whenever there is power applied to the controller.
- MCL (LED 2) Motor Current Limit — Will illuminate whenever the current to the motor is at the level determined by the Motor Current Limit Adjustment Potentiometer (P7).
- OLT (LED 3) The Overload Timer — Illuminates whenever the controller output current exceeds the level determined by potentiometer P5 (overload adjust). If this level is exceeded for 1 minute the controller faults on Overload (OLD) and the Overload (LED 4) OLD (IL8) will light. It is important to recognize that the overload timing circuitry has an electronic memory characteristic much as a thermal overload unit possesses a thermal memory. The memory characteristic functions such that it requires approximately the same amount of time for the timer to reset as was required to

accumulate that amount of time. For example, after faulting on OLD approximately 1 minute is required to reset the timer. If the Main Control Board fault reset button was depressed 10 seconds after faulting on OLD and the controller was started with an overload condition present (LED 3 illuminated) it would be only 10 seconds before the controller faulted on OLD (as opposed to 60 seconds initially). Along the same lines the (LED 3) OLT does not have to be activated continuously for 60 seconds, but rather, must only average on for 60 seconds. The above comments relating to the electronic memory characteristic are valid only if power to the controller is not removed and reapplied. The removal of power from the controller results in the immediate reset of the OLT.

- OLD (LED 4) Overload — Will illuminate when the controller output current has exceeded the current setting of the Overload Threshold Potentiometer (P8) for one minute. To extinguish this LED will require the controller to be reset.
- OT (LED 5) Overtemperature — and precharge contactor failure. Will illuminate if the controller is subject to excessive ambient temperature or upon loss of cooling air. Will also illuminate if the precharge contactor fails to pick up when power is applied to the controller. To extinguish this LED will require the controller to be reset.
- ST (LED 6) Shoot Through — Will illuminate when the dc bus voltage falls below 100v or 50v, the level being determined by the system voltage selection switch (SW6). To extinguish this LED will require the controller to be reset.
- OV (LED 7) Overvoltage — Will illuminate whenever the bus voltage exceeds 900vdc or 450vdc, the level is determined by the System Voltage Selection switch (SW6). To extinguish this LED will require the controller to be reset.
- GF (LED 8) Ground Fault — Will illuminate when there is current flowing from the controller output to ground. When ground current is detected, trip out will be instantaneous. To extinguish this LED will require the controller to be reset.

- IOC (LED9) Instantaneous Overcurrent — Will illuminate when there is 135% of the controller peak maximum output rated current sensed by the output current transformers. To extinguish this LED will require the controller to be reset.
- UV (LED10) Undervoltage — Will illuminate whenever line voltage to the controller is less than 87.5% of the rated voltage. This LED will extinguish when line voltage is 95% of the rated voltage.
- BUV (LED11) Bus Undervoltage — Will illuminate whenever the bus voltage is less than 400vdc or 200vdc, the level is determined by the system voltage selection switch (SW6).
- DE (LED12) Drive Enable — Will illuminate whenever the drive is running.
- PUD (LED13) Power Up Delay — Illuminates nominally for 1.5 seconds when power is initially applied to the controller. If the following conditions occur, the LED will also be illuminated:
  1. An undervoltage condition
  2. A closed circuit between TB1-33 and TB1-22 (Fault reset closed) see Section 11.0, Drawing 11.7.3.
  3. An open circuit between TB1-3 and TB1-22 (Fault Reset Open). This circuit will be used with Isolation-Bypass. See Section 11.0, Drawing 11.7.3.

**7.2 GATE DRIVER BOARD LED**

- IL1- This LED will not illuminate until the controller is operating. During controller operation the LED will illuminate continuously.

**7.3 POWER INTERFACE BOARD NEON**

- IL1- This Neon indicates presence of dc bus voltage at the inverter. This Neon should be illuminated anytime power is applied to the controller. The Neon will remain illuminated after power is removed from the controller until the voltage across the dc bus is less than 100vdc.

**7.4 STAND-BY MODE LAMP STATUS**


There are a large variety of possible lamp indications while the controller is operating, however it is possible to predict the condition of most of the lamps while in a stand-by condition. Standby is defined as "Power applied with the drive stopped". The following tabulation contains the lamp conditions for the stand-by mode.

Lamps	On	Off	Indeterminate	Comments
Main Control Board	X			
PWR		X		May flicker momentarily when power is applied
UV		X		
OV		X		
ST		X		
GF		X		
IOC		X		
OLD		X		
OT		X		
OLT		X		
PUD		X		Illuminates for approximately 1.5 sec when power is applied and then extinguishes
BUV		X		
MCL		X		
DE		X		
Gate Driver Board				
IL1		X		6 of these/1 for each gate driver
Power Interface Board Neon	X			



8.0 POTENTIOMETER, SELECTION SWITCH, LED & SNIP-OUT COMPONENT PLACE-  
MENT CHART


8.1 MAIN CONTROL BOARD



9.0 CONTROLLER OPERATION

9.1 BLOCK DIAGRAM DESCRIPTION

FIGURE 1  
OMEGAPAK CONTROLLER  
BLOCK DIAGRAM



**RECTIFIER**

The rectifier section consists of six power diodes arranged in a three phase, full wave bridge configuration. Its purpose is to change fixed voltage, fixed frequency ac voltage to dc voltage.

**DC LINK**

The dc link couples the rectifier output to the Inverter input. The dc link includes capacitors to smooth the voltage present on the rectifier output plus inductors to limit the rate of change of current during output short circuit conditions.

**INVERTER**

The inverter section consists of six Gate Turn-Off (GTO) Thyristors which, under control of the OMEGAPAK controller electronics, reconstruct a three phase ac waveform for application to a standard three phase ac motor. A Sine Coded Pulse Width Modulation (PWM) switching technique is used.

Section 11, drawing 11.1.1 or 11.1.3 details the controller power circuit.

**CONTROLLER ELECTRONICS**

Electronic circuitry located on a main control board generates all signals necessary to control the turn-on and turn-off of the Inverter GTOs for controlling the output frequency and voltage. The electronics also contains circuitry to protect the controller against various fault conditions and Light Emitting Diodes (LEDs) to indicate controller status. Refer to Section 11, Drawing

11.7.3 for a block diagram of the controller electronics.

9.2 CONTROL CIRCUIT SEQUENCE

The flexibility of available pilot devices to control the OMEGAPAK controller makes possible a wide range of control circuit sequences. The descriptions of operation have been limited to those which are most commonly used.

9.2.1 Pilot Lights, Elapsed Time Meter and Heat Sink Fan(s)

For pilot lights, elapsed time meter and heat sink fan control circuit sequence, refer to Section 11.0, diagram 11.2.1 and the description below.

**MOD P16**

The Power On light (if used) will illuminate when power is applied to the controller.

**MOD R16**

The Run light (if used) will illuminate when the Drive Run Relay (DRR) N.O. contact closes. This same relay contact will also energize the heat sink and internal fans relay.

**MOD F16**

The Drive Fail light (if used) will illuminate when the Drive Fail Relay (DFR) N.C. contact closes. This light is normally not lighted until a controller protective circuit has caused an abnormal shutdown, dropping out the drive fail relay (DFR).

**MOD T15**

The Elapsed Time Meter (if used) will be energized when the Drive Run Relay (DRR) N.O. contact closes.

9.2.2 Start-Stop Push Buttons and Manual Speed Potentiometer (MOD S10) (Class 9001, Type CA-31 Assembled Control Station)

For operation of the control circuit sequence, refer to Section 11.0, diagram 11.2.2 and the description following:

**Power Up Delay**

When power is first applied to the controller, the power up delay circuit will transmit a 1.5-second signal that is applied to fault latch circuits to ensure reset of the latches when the drive is energized. In addition, this Power Up Delay or Reset signal is OR-ed with fault signals and applied to the Run Command Relay and

Drive Run Relay Circuits to prevent energizing of these relays until power up is complete. During operation, if an AC Under-voltage condition occurs, there will also be a power up reset signal when voltage recovers. Two external Reset buttons can produce the same effect as the Power Up Delay. Fault reset open produces a reset by opening connection between TB1-3 and TB1-22. Fault reset closed produces a reset by shorting TB1-33 to TB1-22.

### Starting Sequence

- A. Pressing the Start push button will energize the Run Command Relay (RCR) and the Drive Run Relay (DRR). This will cause the RCR N.O. Contact between terminals 40 and 34 to close to seal around the Start push button. At the same time, the Drive Enable (DE) LED will light.
- B. The controller should now be operating with the output frequency controlled by the manual speed potentiometer.

### Normal Stopping Sequence

- A. Pressing the Stop push button deenergizes the RCR causing the electronics to drop out of the Run Mode and the RCR N.O. Contact between terminals 40 and 34 to open breaking the seal around the Start push button.
- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.
- C. The controller is now stopped.

### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR and DFR relays deenergized until the controller is reset.
- B. The controller will stop immediately and the motor will coast to a stop. The Drive Fail Light (if used) will illuminate.

### 9.2.3 Hand-Automatic Selector Switch, Start-Stop Push Buttons and Manual Speed Potentiometer (Mod. No. A10) (Class 9001, Type CA-42 Assembled Control Station)

For operation of the control circuit sequence, refer to Section 11.0, diagram 11.2.3 and the description below:

#### Hand Mode

- A. Placing the Hand-Auto (H-A) Selector Switch in the Hand position causes the following:

- 1) Opens the circuit between terminals 91 and 34 disabling the automatic start contacts.
- 2) Closes the circuit between terminal 89 and the Stop push button enabling the Start-Stop push buttons.
- 3) Opens the circuit between terminal 22 (-V unreg.) and terminal 78 (Hand/Auto) reference select to switch control of the output frequency to the manual speed potentiometer.

#### Power Up Delay

When power is first applied to the controller, the power up delay circuit will transmit a 1.5-second signal that is applied to fault latch circuits to ensure reset of the latches when the drive is energized. In addition, this Power Up Delay or Reset signal is OR-ed with fault signals and applied to the Run Command Relay and Drive Run Relay Circuits prevent energizing of these relays until power up is complete. During operation, if an AC Under-voltage condition occurs, there will also be a power up reset signal when voltage recovers. Two external Reset buttons can produce the same effect as the Power Up Delay. Fault reset open produces a reset by opening connection between TB1-3 and TB1-22. Fault reset closed produces a reset by shorting TB1-33 to TB1-22.

#### Starting Sequence

- A. Pressing the Start push button will energize the Run Command Relay (RCR) and the Drive Run Relay (DRR). This will cause the RCR N.O. Contact between terminals 40 and 34 to close to seal

around the Start push button. At the same time, the Drive Enable (DE) LED will light.

- B. The controller should now be operating with the output frequency controlled by the manual speed potentiometer.

#### Normal Stopping Sequence

- A. Pressing the Stop push button deenergizes the RCR causing the electronics to drop out of the Run Mode and the RCR N.O. Contact between terminals 40 and 34 to open breaking the seal around the Start push button.
- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.
- C. The controller is now stopped.

#### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR, and DFR relays deenergized until the controller is reset.
- B. The controller will stop immediately and the motor will coast to a stop. The drive fail light (if used) will illuminate.

#### Auto Mode

- A. Placing the Hand-Auto (H-A) selector switch in the Auto position causes the following:
- 1) Opens the circuit between terminal 89 and the Stop push button disabling the Start-Stop push buttons.
  - 2) Closes the circuit between terminals 91 and 34 enabling the automatic start contact.
  - 3) Closes the circuit between terminal 22 (-V unreg.) and terminal 78 (Hand/Auto) reference select to switch control of the output frequency to an analog input follower signal.

#### Start Sequence

- A. Closing the user supplied contact between terminals 44 and 89 energizes the Run Command Relay (RCR) and the Drive Run Relay (DRR). The Drive Enable (DE) LED will light.

Energizing the RCR causes the following:

- 1) The RCR N.O. contact between terminals 40 and 34 closes but has no effect since power to the Stop push button has been disabled.
- B. The controller should now be operating with the output frequency controlled by the analog input follower signal.

#### Normal Stopping Sequence

- A. Opening the automatic start contact deenergizes the RCR causing the electronics to drop out of the run mode and the RCR N.O. contact between terminals 40 and 34 opens, however, this contact has no effect in the auto mode.
- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.
- C. The controller is now stopped.

#### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR, and DFR relays de-energized until the controller is reset.
- B. The controller will stop immediately and the motor will coast to a stop.
- C. A DFR N.C. contact will close illuminating the Drive Fail pilot light (if used). Refer to Section 11.0 diagram 11.2.1.

### 9.2.4 Hand-Off-Automatic selector switch, and Manual Speed potentiometer (Mod. No. H10)

For operation of the control circuit sequence, refer to Section 11.0, diagram 11.2.4 and the description below:

#### Power Up Delay

When power is first applied to the controller, the power up delay circuit will transmit a 1.5-second signal that is applied to fault latch circuits to ensure reset of the latches when the drive is energized. In addition, this Power Up Delay or Reset signal is OR-ed with fault signals and applied to the Run Command Relay and Drive Run Relay circuits to prevent energizing of these relays until power up is complete. During operation, if an AC Under-voltage condition occurs, there will also be a power up reset signal when voltage recovers. Two external Reset buttons can produce the same effect as the Power Up Delay. Fault Reset Open produces a Reset by opening connection between TB1-3 and TB1-22. Fault Reset Closed produces a reset by shorting TB1-33 to TB1-22.

#### Hand Mode

- A. Placing the Hand-Off-Auto (H-O-A) selector switch in the Off position disables controller operation.
- B. Placing the Hand-Off-Auto (H-O-A) selector switch in the Hand position causes the following:
  - 1) The H-O-A contact between terminals 91 and 34 opens disabling the Automatic Start contact.
  - 2) The H-O-A contact between terminals 22 (-V unreg.) and 78 (Hand-Auto) opens causing the output frequency to respond to the manual speed potentiometer.
  - 3) The H-O-A contact between terminals 89 and 34 closes, energizing the Run Command Relay (RCR) coil and the Drive Run Relay (DRR) coil. The Drive Enable (DE) LED will light.
- C. Energizing RCR causes the RCR N.O. contact between terminals 40 and 34 to close but has no effect.

- D. The controller should now be operating with the output frequency controlled by the manual speed potentiometer.

#### Normal Stopping Sequence

- A. Moving the H-O-A selector switch to the Off position deenergizes the RCR causing the RCR N.O. contact between terminals 40 and 34 to open, however, this contact has no effect in the hand mode.
- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.
- C. The controller is now stopped.

#### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR, and DFR relays deenergized until the controller is reset.
- B. The controller will stop immediately and the motor will coast to a stop.
- C. A DFR N.C. contact will close illuminating the Drive Fail pilot light (if used). Refer to Section 11.0 diagram 11.2.1.

#### Auto Mode

- A. Placing the Hand-Off-Auto (H-O-A) selector switch in the Auto mode causes the following:
  - 1) The H-O-A contact between terminals 91 and 34 closes to enable the controller to start when the automatic start contact closes.
  - 2) The H-O-A contact between terminals 89 and 34 opens preventing the controller from being manually started.
  - 3) The H-O-A contact between terminals 22 (-V unreg.) and 78 (Hand-Auto) closes causing the output frequency to respond to an analog input follower signal.

- B. Closing the automatic start contact energizes the Run Command Relay (RCR) and the Drive Run Relay (DRR). The Drive Enable (DE) LED will light. Energizing the RCR causes the RCR N.O. contact between terminals 40 and 34 to close but has no effect.
- C. The controller should now be operating with the output frequency controlled by the analog input follower signal.

#### Normal Stopping Sequence

- A. Opening the automatic start contact or moving the H-O-A switch to the OFF position deenergizes the RCR removing the start-stop signal at TB1-42. The RCR N.O. contact between terminals 40 and 34 opens, however, this contact has no effect.
- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.
- C. The controller is now stopped.

#### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR, and DFR relays deenergized until the controller is reset.
- B. The controller will stop immediately and the motor will coast to a stop.
- C. A DFR N.C. contact will close illuminating the Drive Fail pilot light (if used). Refer to Section 11.0 diagram 11.2.1.

#### 9.2.5 OMEGAPAK 2000 controller with optional Isolation Contactor (Mod C13) or optional Isolation/Bypass Contactor (Mod E13) and Hand-Off-Auto Selector Switch and Manual Speed Potentiometer (Mod H10).

For operation of the control circuit sequence, refer to Section 11.0 diagram 11.2.4 and the description below.

#### Operation With Isolation Contactor

(Diagram 11.2.4) Note: AFC-Off-Line switch is not used and a jumper is installed between terminals 22 and 3.

#### Power Up Delay

When power is first applied to the controller, the power up delay circuit will transmit a 1.5-second signal that is applied to fault latch circuits to ensure reset of the latches when the drive is energized. In addition, this Power Up Delay or Reset signal is OR-ed with fault signals and applied to the Run Command Relay and Drive Run Relay circuits to prevent energizing of these relays until power up is complete. During operation, if an AC Under-voltage condition occurs, there will also be a power up reset signal when voltage recovers. Two external Reset buttons can produce the same effect as the Power Up Delay. Fault Reset Open produces a Reset by opening connection between TB1-3 and TB1-22. Fault Reset Closed produces a reset by shorting TB1-33 to TB1-22.

#### Hand Mode

- A. Placing the Hand-Off-Auto (H-O-A) selector switch in the Hand position causes the following:
  - 1) The H-O-A contact between terminal 91 and 34 opens disabling the Automatic Start contact.
  - 2) The H-O-A contact between terminals 22 (-V unreg.) and 78 (Hand-Auto) opens causing the output frequency to respond to the manual speed potentiometer.
  - 3) The H-O-A contact between terminals 89 and 34 closes, energizing the Run Command Relay (RCR) coil and the Drive Run Relay (DRR) coil. The Drive Enable (DE) LED will light.
- B. Energizing RCR causes the following:
  - 1) The RCR N.O. contact between terminals 37 and 39 closes to energize the Isolation Contactor (IC) (refer to diagram 11.3.12).
  - 2) The RCR N.O. contact between terminals 40 and 34 closes however, this contact has no effect.
- C. Energizing the Isolation Contactor (IC) shown on 11.3.12 causes the following:
  - 1) The IC N.O. contact between terminal 41 and 42 closes completing the start circuit.
  - 2) The IC N.C. contact between terminals 41 and 86 opens however, this contact has no effect.

- D. The controller should now be operating with the output frequency controlled by the Manual Speed Potentiometer.

#### Normal Stopping Sequence

- A. Moving the H-O-A selector switch to the OFF position deenergizes the RCR causing the electronics to drop out of the run mode and the following:

- 1) The RCR N.O. contact between terminals 40 and 34 opens, however, this contact has no effect.
- 2) The RCR N.O. contact between terminal 37 and 39 opens but the Isolation Contactor does not drop out because the DRR N.O. contact between terminals 45 and 46 remains closed. Refer to Section 11.0, Diagram 11.2.4.

- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.

- C. Dropping out DRR also causes IC to be deenergized.

#### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR and DFR relays deenergized until the controller is reset.

- B. The controller will stop immediately and the motor will coast to a stop.

- C. A DFR N.C. contact will close illuminating the Drive Fail pilot light (if used). Refer to Section 11.0 diagram 11.2.1.

#### Auto Mode

- A. Placing the Hand-Off-Auto (H-O-A) selector switch in the Auto mode causes the following:

- 1) The H-O-A contact between terminals 91 and 34 closes to enable the controller to start when the automatic start contact closes.

- 2) The H-O-A contact between terminals 89 and 34 opens preventing the controller from being manually started.

- 3) The H-O-A contact between terminals 22 (-V unreg.) and 78 (Hand/Auto) closes causing the output frequency to respond to an analog input follower signal.

- B. Closing the automatic start contact energizes the Run Command Relay (RCR) and the Drive Run Relay (DRR). The Drive Enable (DE) LED will light.

- C. Energizing RCR causes the following:

- 1) The RCR N.O. contact between terminals 40 and 34 closes, however, this contact has no effect.
- 2) The RCR N.O. contact between terminals 37 and 39 closes to energize the Isolation Contactor (IC). See Section 11.0, diagram 11.2.4.

- D. Energizing the Isolation Contactor (IC) shown on Diagram 11.3.12 causes the following:

- 1) The IC N.O. contact between terminal 41 and 42 closes completing the start circuit.
- 2) The IC N.C. contact between terminals 41 and 86 opens, however, this contact has no effect.

- E. The controller should now be operating with the output frequency controlled by the analog input signal.

#### Normal Stopping Sequence

- A. Opening the automatic start contact deenergizes the RCR causing the electronics to drop out of the Run Mode and the following:

- 1) The RCR N.O. contact between terminals 40 and 34 opens, however, this contact has no effect in the auto mode.

- 2) The RCR N.O. contact between terminal 37 and 39 opens but the Isolation Contactor does not drop out because the DRR N.O. contact between terminals 45 and 46 remains closed. Refer to Section 11.0, Diagram 11.2.4.

- B. With SW2 closed (See Figure 6.3), the motor will decelerate to a stop and DRR will drop out when the output frequency has reached minimum. With SW2 open, the motor will coast to a stop and DRR will drop out immediately after the controller is told to stop.
- C. Dropping out DRR also causes IC to be deenergized.

#### Abnormal Stopping Sequence

- A. Operation of a protective circuit will cause immediate controller shutdown upon occurrence of a fault condition. The electronic circuitry will keep the RCR, DRR, and DFR relays deenergized until the controller is reset.
- B. The controller will stop immediately and the motor will coast to a stop.
- C. An additional DFR N.C. contact will close illuminating the Drive Fail pilot light (if used). Refer to Section 11.0 diagram 11.2.1.

#### Operation With Isolation/Bypass Contactors

(Diagrams 11.2.4 and 11.3.13 or 11.3.14). Note: AFC-Off-Line switch used — jumper between terminals 22 and 3 removed.

#### AFC (Adjustable Frequency Controller) Mode

- A. Placing the AFC-Off-Line selector switch in the AFC position causes the following:
  - 1) The AFC-Off-Line contact between terminals 22 (-V unreg.) and 3 (Fault Reset Open) closes resetting the controller and permitting normal operation.
  - 2) The AFC-Off-Line contact on diagram 11.3.13 or 11.3.14 opens preventing the Bypass contactor from being energized.
- B. The controller operation is now as described for the Isolation Contactor.

#### Bypass Mode

- A. Placing the AFC-Off-Line selector switch in the Line position causes the following:
  - 1) The AFC-Off-Line contact between terminals 22 (-V unreg.) and 3 (Fault Reset Open) opens to place the controller in the stop (Reset) mode.
  - 2) The AFC-Off-Line contact on diagram 11.3.13 or 11.3.14 closes to energize the Bypass Contactor (BC).
- B. The motor line starts and is now operating at constant speed from ac line voltage and frequency and will continue to operate independent of the adjustable frequency controller.



**10.0 TROUBLESHOOTING & MAINTENANCE GUIDE****CONTENTS****10.0.1 MAINTENANCE****10.0.2 TROUBLESHOOTING, GENERAL COMMENTS****10.1 GENERAL SYMPTOMS**

- \*1. Will not start
- \*2. Will not accelerate load
- \*3. Accelerates load too slowly
- 4. Excessive motor temperature

**10.2 LED ANNUNCIATED FAULTS**

- \*1. Shoot through (ST) — LED 6
- \*2. Instantaneous Overcurrent (IOC) — LED 9
- \*3. Overvoltage (OV) — LED 7
- \*4. Ground Fault (GF) — LED 8
- \*5. Bus Undervoltage (BUV) — LED 11
- \*6. Overload (OLD) — LED 4
- 7. Overtemperature (OT) — LED 5

**10.3 MISCELLANEOUS**

- 1. Undervoltage (UV) — LED 10

**10.4 TROUBLESHOOTING PROCEDURES**

- \*1. Gating
- 2. Voltage output
- \*3. Control power supply
- 4. Voltage balance
- 5. Shorted inverter GTO
- 6. Voltage feedback
- 7. Bus capacitor

**10.5 TROUBLESHOOTING DATA**

**\*Designates Troubleshooting Flow Charts — located at the end of Section 10.**

### 10.0.1 MAINTENANCE

During normal use, the drive controller will require minimum maintenance. However, good maintenance practice requires periodic inspection of the controller. The maintenance periods should be scheduled based on the particular operating environment of the controller, but should not exceed one year.

#### CAUTION

**ONLY AUTHORIZED SERVICE PERSONNEL FAMILIAR WITH THIS EQUIPMENT SHOULD BE ALLOWED TO SERVICE THE CONTROLLER.**

General maintenance procedures for Square D control gear are covered in Square D publication 30072-200-50. Procedures specific to this controller are as follows.

1. Standby lamp status should be verified per Section 7.4.
2. Drive controller operation should be observed. Any deviations from normal operation may be an indication of a controller malfunction. A thorough investigation should be made to determine the cause.
3. Check operation of any push-to-test pilot lamps.
4. **Remove all power**

#### DANGER

##### HAZARD OF ELECTRICAL SHOCK OR BURN

**BEFORE SERVICING, TURN OFF POWER SUPPLY(S) TO THIS EQUIPMENT. WAIT 5 MINUTES. MEASURE CAPACITOR VOLTAGES TO VERIFY THAT THEY ARE ZERO. DO NOT SHORT ACROSS CAPACITORS WITH VOLTAGE PRESENT.**

5. Remove the shroud covering the external heat sink fins by removing the two external screws near the center (front) of the shroud and the two screws on the inside of the controller door near the top. Unplug the fan power cable(s) from the shroud fan(s).
6. Inspect and clean all air passageways using a vacuum cleaner. *Do not* use a compressed air source.
7. Inspect and clean all insulation systems within the controller using a vacuum cleaner. *Do not* use a compressed air source. *Do not "megger" controller!*
8. Check integrity of all mechanical fasteners.
9. Check integrity of all electrical fasteners and joints.
10. Check controller grounding means.
11. Check capacitor bank for damaged or bulging cans. Replace as required.
12. Inspect all electrical components for damage.
13. Reconnect the fan power cable(s) from the shroud fan(s) and reinstall the shroud.

#### DANGER

##### HAZARD OF ELECTRICAL SHOCK OR BURN

**DO NOT ENERGIZE OR ATTEMPT TO OPERATE THE CONTROLLER WITH THE SEMICONDUCTOR ASSEMBLY IN THE SERVICE POSITION. ALL HEATSINK ASSEMBLIES ARE ELECTRICALLY HOT WHEN THE CONTROLLER IS ENERGIZED AND WHILE THE DC BUS CAPACITORS ARE CHARGED.**

**10.0.2 TROUBLESHOOTING, GENERAL**

A number of diagnostic and status indicating lights (refer to Section 7.0, Diagnostic Indicating LED's and Neon Light) have been included on the Main Control Board, Power Interface Board and Gate driver Boards. The intent of these lights is to provide visual indication of a number of controller operating and protective circuit functions to assist in maintenance and troubleshooting.

The following troubleshooting guide can best be utilized by observing the status of the lights and reviewing the symptoms listed to determine which possible problems could cause the observed light pattern. To view the lights, the controller door must be open with power applied to the controller. If the controller trips while operating, the lights must be viewed before power is removed because removing and re-applying power resets the fault indicators.

**CAUTION**

**ONLY AUTHORIZED SERVICE PERSONNEL FAMILIAR WITH THIS EQUIPMENT SHOULD BE ALLOWED TO SERVICE THE CONTROLLER.**

**DANGER****HAZARD OF ELECTRICAL SHOCK OR BURN**

**MANY PARTS INCLUDING ELECTRONIC PRINTED WIRE BOARDS IN THIS CONTROLLER OPERATE AT LINE VOLTAGE. DO NOT TOUCH. USE ONLY ELECTRICALLY INSULATED TOOLS WHILE MAKING ADJUSTMENTS.**

**DANGER****HAZARD OF ELECTRICAL SHOCK OR BURN**

**CERTAIN ADJUSTMENTS AND TEST PROCEDURES REQUIRE THAT POWER BE APPLIED TO THIS CONTROLLER. WHEN WORKING WITH ENERGIZED EQUIPMENT, EXTREME CAUTION MUST BE EXERCISED AS HAZARDOUS VOLTAGES EXIST. THE ENCLOSURE DOOR MUST BE CLOSED AND SECURED WHILE TURNING ON POWER, OR STARTING AND STOPPING THIS CONTROLLER.**

When used in conjunction with the diagnostic and status indicating lights this guide facilitates troubleshooting to the individual printed wiring board level.

The troubleshooting procedure is organized into 4 basic units. The first unit (10.1) covers general problems which are identified by a basic description (e.g. — "Controller will not start"). The second section (10.2) consists of specific faults annunciated by LED illuminations (e.g. — "Instantaneous Over-current (IL7)"). The third section (10.3) attempts to include those items not covered in 1 or 2 such as LED illuminations which contain useful problem-solving information but are not fault indicators. The fourth and last section (10.4) is comprised of troubleshooting techniques which support the first 3 sections.

**If troubleshooting indicates the necessity of component replacement, observe all precautions.**

**DANGER****HAZARD OF ELECTRICAL SHOCK OR BURN**

**BEFORE SERVICING, TURN OFF POWER SUPPLY(S) TO THIS EQUIPMENT. WAIT 5 MINUTES. MEASURE CAPACITOR VOLTAGES TO VERIFY THAT THEY ARE ZERO. DO NOT SHORT ACROSS CAPACITORS WITH VOLTAGE PRESENT.**

When contacting Square D for troubleshooting assistance or requesting service, it is necessary to have the information requested on the controller trouble sheet available. If the controller is to be returned to Square D, a completed copy of the sheet must be inserted in the controller before packing for shipment. Several copies of the controller trouble sheet are provided in Section 10.5.

#### 10.1.4 EXCESSIVE MOTOR TEMPERATURE

Motor Overheating can result from the following items:

1. Motor incorrectly sized for load. Measure motor current and compare to nameplate rating.
2. Since most motors are cooled by internal shaft-mounted fans, the motor rated current capacity will decrease with speed due to decreased fan speed. If substantial motor torque is required at low speed, motor overtemperature may occur. The motor manufacturer should be consulted to determine the correct motor selection for such applications.
3. Verify that voltage output is correct per 10.4.2.

NOTE: With the advent of modern insulation materials, many motors are capable of operating at relatively high winding temperatures. Therefore, motors which seem hot-to-the-touch may be operating well within their temperature limits. The motor nameplate should be consulted as to the class of the motor's insulation system. To properly determine a motor's temperature, the procedures described in NEMA MG-1 may be followed.

### 10.2.7 OVERTEMPERATURE (OT) LED (LED 5)

The overtemperature (OT) LED (LED 5) will illuminate whenever the normally closed switch, as shown on the control elementary diagram (refer to the table of contents under Section 11 to determine the drawing number) connected between terminals TB1-28 and TB1-22 through tie-point TB1-18 is opened. In this event the following items should be checked:

1. Excessive ambient temperature per Section 3.1.4.
2. Controller cooling fan failure (location per Section 4).
3. Loose or defective electrical connection.
4. Check for tripped motor thermal switch if the motor is so equipped. Refer to Section 10.1.4, excessive motor temperature.
5. Dirty heatsink assembly or blocked air flow. See Section 10.0.1.

### 10.3.1 UNDERVOLTAGE (UV) (LED 10)

The undervoltage LED is illuminated whenever the controller input line voltage falls below 87.5% of rated line voltage (per Section 3.1.1). There is hysteresis in this circuitry so that voltage must rise back to a level of 95% rated voltage before the undervoltage condition is removed. While in a UV condition the precharge relay is de-energized and the drive is inhibited from running. In the event of an undervoltage condition consider the following items:

1. Low AC input per specifications of Section 3.1.1.
2. Momentary AC line dip — controller will automatically reset and run if 2-wire control is used. Three-wire control circuits will require that the start button be depressed.
3. Refer to 10.4.3 and perform a control power supply check.

### 10.4.2 VOLTAGE OUTPUT

Improper voltage output may cause Overload, Instantaneous Over Current, or insufficient torque. Perform the following to verify that the voltage output is correct.

1. Perform the voltage balance procedure per 10.4.4. If no imbalance is found, continue to the next step.
2. **Remove all power. Read and observe caution notes concerning controller servicing.**
3. With the motor leads disconnected from terminals T1, T2, and T3, adjust the input speed signal until the voltage between TB1-4(+) and TB1-6 (common) on the Main Control Board (refer to Figure 8.1) is 1.25 VDC.
4. With the controller at this frequency, measure the voltage between TB1-26(+) and TB1-6 (common). Compare this measured voltage (V) to the voltage listed in Table 1 for the switch configuration of the controller under examination. The measured voltage should be within  $\pm 10\%$  of the tabulated value.
5. If the conditions of (4) are not satisfied, confirm the integrity of the voltage feedback per 10.4.6.
6. If voltage feedback is functioning properly, replace the Main Control Board.

TABLE 1

Main Control Board Dip Switch Settings<sup>①</sup>

Input Voltage	Motor Voltage	Resistors <sup>②</sup>						V (± 10%) @ TB1-26
		R170 R180	SW1	SW3	SW6	SW7	SW8	
200V	200V	I	X	X	O	O	*	.87V
230V	200V	I	X	X	O	O	*	.87V
230V	230V	I	X	O	O	O	*	1.00V
460V	400V	I	O	O	X	X	*	1.74V
460V	460V	I	O	O	X	O	*	2.00V
200V	200V	R	X	X	O	O	*	.44V
230V	230V	R	X	O	O	O	*	.50V
460V	400V	R	O	O	X	X	*	.87V
460V	460V	R	O	O	X	O	x	1.00V

X-Closed Switch (On)

O-Open Switch (Off)

\* -Either position is acceptable

① Refer to Section 6, controller adjustments for additional information on the proper setting of the dip switches.

② I = Installed, R = Removed, refer to Figure 8.1 Snip-out Resistors

#### 10.4.4 CONTROLLER OUTPUT VOLTAGE MEASUREMENT

Controller output voltage can indicate a potential gating problem. The following procedure illustrates this concept:

1. Remove all power. Read and observe caution notes concerning controller servicing.
2. With all power removed, remove motor leads from terminals T1, T2, and T3 so that controller output is open circuited. Read and observe caution notes concerning controller servicing.
3. Start the controller and adjust the output frequency to 60 HZ by varying input speed signal until the DC voltage between TB1-4(+) and TB1-6 (common) is 2.5VDC (see Section 8.1 for location of TB1). Note: if the controller is capable of hand or automatic operation, the hand mode should be used and speed should be varied with the manual speed potentiometer.
4. Measure the line to line output voltages from T1 to T2, T2 to T3, and T1 to T3 (see Section 4.0 for location). These voltages should be within 5% of each other. The actual voltage reading is not important. Because of the complex output waveform, different voltmeters may read different values. The major concern is that all three readings indicate balanced voltages. If not, this indicates a problem in a gating channel. The output which is common to the two lowest line-to-line readings is driven by the two suspect gating channels. As an example, suppose  $V(T1-T2) = 400V$ ,  $V(T2-T3) = 500V$ , and  $V(T1-T3) = 400$ . Since T1 is common to  $V(T1-T2)$  and  $V(T1-T3)$ , the two lowest readings, there is a problem in the gating circuitry or GTOs that drive that terminal.

To correct the problem, the following items should be replaced sequentially. **Read and observe caution notes concerning controller servicing.**

1. The pair of gate drivers associated with that output terminal (illustrated in Section 4).
2. Ribbon cable between the Main Control Board and Power Interface Board.
3. Main Control Board
4. Power Interface Board — be certain to use two known good Gate Drivers in the positions which drive the suspect terminal.

If Steps 1 - 4 above do not correct the problem, contact the factory.

#### 10.4.5 SHORTED INVERTER GATE TURN-OFF THYRISTOR (GTO)

**Remove all power from the controller. Read and observe caution notes concerning controller servicing.** Disconnect the motor leads at terminals T1, T2 and T3. With an ohmmeter on the RX10 scale perform the measurements in Table 2. If a low resistance measurement is encountered where a high resistance measurement is expected, a shorted GTO is indicated. The terms high and low resistance are relative and comparison with the other measurements should clarify a questionable reading. Note: A shorted GTO could be the result of some other problem. Failure to determine the cause may result in failure of the replacement GTO. Contact your local Square D representative if a shorted GTO is suspected.

TABLE 2

Ohmmeter* + Lead	Ohmmeter* - Lead	Measurement (Resistance)
+ Bus	T1	High
+ Bus	T2	High
+ Bus	T3	High
T1	+ Bus	Low
T2	+ Bus	Low
T3	+ Bus	Low
- Bus	T1	Low
- Bus	T2	Low
- Bus	T3	Low
T1	- Bus	High
T2	- Bus	High
T3	- Bus	High

\*Refer to Section 4, controller photos to determine the location of terminals.

#### 10.4.6 VOLTAGE FEEDBACK

This procedure verifies the integrity of the controller output voltage sense resistors, both DC bus voltage and motor terminal voltages and the ribbon cable which conveys voltage feedback information from the Power Interface Board to the Main Control Board. Defective voltage feedback usually results in Instantaneous Over Current (LED 9) or Shoot Through trips (LED 6).

1. **Remove all power. Read and observe caution notes concerning controller servicing.**
2. With all power removed, disconnect the motor leads from terminals T1, T2 and T3. Refer to Section 4 for the location of T1, T2 and T3.
3. Remove the ribbon cable between the Main Control Board and the Power Interface Board.
4. Place one lead of an ohmmeter on test point TP3 of the Power Interface Board (PIB) and the other lead on terminal T1 (refer to Section 4 to determine the location). The meter should read 3 megohms. If not, replace the Power Interface Board.
5. Repeat Step 4 for test point TP4 and terminal T2.
6. Repeat Step 4 for test point TP5 and terminal T3.
7. Repeat Step 4 for test point TP1 and + bus terminal.
8. Repeat Step 4 for test point TP2 and - bus terminal.
9. Place the meter on the RX1 scale and check the continuity of the ribbon cable. Each conductor should read two ohms or less. If any are of a higher value, replace the ribbon cable.

### 10.4.7 BUS CAPACITOR

An open bus capacitor may result in overvoltage (OV) or shoot through (ST). A shorted bus capacitor will result in blown incoming line fuses. Capacitors which initially fail shorted, blowing the input line fuses, will generally open-circuit after the internal protective mechanism operates to clear the capacitor's internal short circuit. This condition can be visually detected by examining the top of the capacitor. The top of the capacitor will be bulged outward creating a dome shape. This failed capacitor and any blown input line fuses should be replaced and the possible loss of input lines to the controller should be investigated. If a failed capacitor is suspected, but is not visually detectable, a general indication of capacitor condition can be obtained with an analog ohmmeter. **Remove power from the controller. Read and observe caution notes concerning controller servicing.** With the meter scaling at RX1000 connect the meter leads across the capacitor terminals. A shorted capacitor will indicate low resistance, an open capacitor will indicate infinity, and a good capacitor will deflect momentarily and then return to the infinity position.

### 10.5 TROUBLESHOOTING DATA

PLACE THE TROUBLE SHEET WITH THE AUTHORIZED RETURN PAPER RECEIVED FROM YOUR LOCAL SQUARE D REPRESENTATIVE.

The purpose of the "Trouble Sheet" is to obtain as much pertinent information about the controller as possible. By fully filling out the following form the time to repair the controller and the cost of troubleshooting the controller are reduced. The following is an explanation of the type of information needed on this form.

**USER NAME AND ADDRESS:** Where the controller is installed

**PERSON TO CONTACT:** Someone at the user who is familiar with the problem and application. Contact for additional information may be required.

**CONTROLLER DATA:** Completely fill in the sample nameplate given on the bottom of the form.

**MOTOR DATA:** Fill in the requested information. If you have multiple motors give the information for all the motors controlled by the AFC.

**APPLICATION DATA:**

- Ambient temperature
- Type of load being controlled (i.e. conveyor, mixer, pump, fan, etc.)
- Basic power flow from supply to motor. Indicate if any contactors or circuit breakers are installed before the motor, or between the controller and motor. Is there any line bypass or across-the-line start capabilities?
- Is this a multiple motor scheme? Are the motors started all at the same time or sequenced?
- Type of speed control
  - Hand pot, analog input signal (4-20 ma or 0-10V dc).
- If remote control wiring is installed detail the functions (start-stop, Hand-Off-Auto, etc.) and the terminals to which your wiring is connected.

**PROBLEM INFORMATION:**

Description of Symptoms:

- Does fault occur
  - When only power is on the controller
  - When start button is pushed
  - When changing speeds
  - When running at constant speed
  - When stopping
  - When motor load changes
- Does problem have a pattern (i.e. does problems occur at same time during day?) or is the problem random?
- Signs of visual damage (bulging capacitor cans, blown fuses, discoloration on boards)



CONTROLLER TROUBLE SHEET

DETAIL TROUBLESHOOTING STEPS TAKEN

In the service bulletins there are a number of troubleshooting steps to be taken. List the steps taken and the results of those steps. If you have done any troubleshooting on your system detail those steps and results also.

USER NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY, STATE, ZIP \_\_\_\_\_



PERSON TO CONTACT \_\_\_\_\_

PHONE \_\_\_\_\_



PURCHASER (DISTRIBUTOR) \_\_\_\_\_ PO. # (IF AVAILABLE) \_\_\_\_\_

CONTROLLER DATA: (FILL IN NAMEPLATE INFORMATION)

1000 CONTROLLER NAMEPLATE

			
OMEGAPAK™			
ADJUSTABLE FREQUENCY CONTROLLER			
CLASS 8804		TYPE	SER
INPUT			
VOLTS			
MAX. WITHSTAND SYM. AMPS RMS			
MAX. AMPS	3PH	1PH	60HZ
OUTPUT		OVERLOAD CAP. % FOR 1 MIN	
H.P.			
VOLTS	0-	0-	0-
3-60/90/120HZ		3PH	S.F. 1.0
MAX. AMPS		O.L. SETTING REFER TO S.B.	
		87	
51140-291-01			

2000 CONTROLLER NAMEPLATE

		MOTOR CONTROLLER	
		CLASS 8804	
BUS RATING	BUS BAR BRACED FOR		
HORIZ			AMP RMS
VERT.		SYM. AVAILABLE	
	MAX		
			
87			51139-242-01

MOTOR DATA:

HP \_\_\_\_\_ VOLTAGE \_\_\_\_\_ FULL LOAD CURRENT \_\_\_\_\_

SERVICE FACTOR \_\_\_\_\_ NEMA DESIGN \_\_\_\_\_ SPEED \_\_\_\_\_

APPLICATION DATA:

APPLICATION (DESCRIBE) \_\_\_\_\_

SPEED RANGE: MAX. SPEED \_\_\_\_\_ MIN. SPEED \_\_\_\_\_ DUTY CYCLE \_\_\_\_\_


CUT ALONG LINE TO DETACH

CONTROLLER TROUBLE SHEET (continued)

PROBLEM INFORMATION:

LED'S THAT ARE ILLUMINATED (MARK ON DRAWING)

NO. OF GATE DRIVER LED'S ON \_\_\_\_\_



LENGTH OF TIME CONTROLLER HAS OPERATED PROPERLY:

\_\_\_\_\_ MONTHS, OR PROBLEM OCCURRED AT START-UP \_\_\_\_\_

DESCRIPTION OF SYMPTOMS \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

DETAIL TROUBLESHOOTING STEPS TAKEN \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

CONTROLLER TROUBLE SHEET

DETAIL TROUBLESHOOTING STEPS TAKEN

In the service bulletins there are a number of troubleshooting steps to be taken. List the steps taken and the results of those steps. If you have done any troubleshooting on your system detail those steps and results also.

USER NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY, STATE, ZIP \_\_\_\_\_



PERSON TO CONTACT \_\_\_\_\_

PHONE \_\_\_\_\_



PURCHASER (DISTRIBUTOR) \_\_\_\_\_ PO. # (IF AVAILABLE) \_\_\_\_\_

CONTROLLER DATA: (FILL IN NAMEPLATE INFORMATION)

1000 CONTROLLER NAMEPLATE

				OMEGAPAK™			
				ADJUSTABLE FREQUENCY CONTROLLER			
				CLASS 8804		TYPE	SER
INPUT							
VOLTS							
MAX. WITHSTAND SYM. AMPS RMS							
MAX. AMPS		3PH		1PH		60HZ	
OUTPUT				OVERLOAD CAP.		% FOR 1 MIN	
H.P.							
VOLTS		0-	0-	0-			
3-60/90/120HZ			3PH		S.F. 1.0		
MAX. AMPS				O.L. SETTING REFER TO S.B.			
				87			
51140-291-01							

2000 CONTROLLER NAMEPLATE

		MOTOR CONTROLLER			
		CLASS 8804			
BUS RATING		BUS BAR BRACED FOR			
HORIZ				AMP RMS	
VERT.			SYM. AVAILABLE		
○		MAX	○		
					
51139-242-01					

MOTOR DATA:

HP \_\_\_\_\_ VOLTAGE \_\_\_\_\_ FULL LOAD CURRENT \_\_\_\_\_

SERVICE FACTOR \_\_\_\_\_ NEMA DESIGN \_\_\_\_\_ SPEED \_\_\_\_\_

APPLICATION DATA:

APPLICATION (DESCRIBE) \_\_\_\_\_

SPEED RANGE: MAX. SPEED \_\_\_\_\_ MIN. SPEED \_\_\_\_\_ DUTY CYCLE \_\_\_\_\_

SQUARE D \_\_\_\_\_ 58


CUT ALONG LINE TO DETACH

**CONTROLLER TROUBLE SHEET (continued)**

PROBLEM INFORMATION:

LED'S THAT ARE ILLUMINATED (MARK ON DRAWING)

NO. OF GATE DRIVER LED'S ON \_\_\_\_\_



LENGTH OF TIME CONTROLLER HAS OPERATED PROPERLY:

\_\_\_\_\_ MONTHS, OR PROBLEM OCCURRED AT START-UP \_\_\_\_\_

DESCRIPTION OF SYMPTOMS \_\_\_\_\_

\_\_\_\_\_

DETAIL TROUBLESHOOTING STEPS TAKEN \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

CONTROLLER TROUBLE SHEET

DETAIL TROUBLESHOOTING STEPS TAKEN

In the service bulletins there are a number of troubleshooting steps to be taken. List the steps taken and the results of those steps. If you have done any troubleshooting on your system detail those steps and results also.

USER NAME \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY, STATE, ZIP \_\_\_\_\_



PERSON TO CONTACT \_\_\_\_\_

PHONE \_\_\_\_\_




PURCHASER (DISTRIBUTOR) \_\_\_\_\_ P.O. # (IF AVAILABLE) \_\_\_\_\_

CONTROLLER DATA: (FILL IN NAMEPLATE INFORMATION)

1000 CONTROLLER NAMEPLATE

				OMEGAPAK™			
				ADJUSTABLE FREQUENCY CONTROLLER			
				CLASS 8804		TYPE _____	
						SER _____	
INPUT							
VOLTS		_____		_____		_____	
MAX. WITHSTAND SYM. AMPS RMS							
MAX. AMPS		3PH		1PH		60HZ	
OVERLOAD CAP. % FOR 1 MIN							
H.P.		_____		_____		_____	
VOLTS		0-		0-		0-	
3-60/90/120HZ		3PH		S.F. 1.0			
MAX. AMPS _____				O.L. SETTING REFER TO S.B. _____			
				87 _____			
51140-291-01							

2000 CONTROLLER NAMEPLATE

		MOTOR CONTROLLER			
		CLASS 8804			
BUS RATING _____		BUS BAR BRACED FOR			
HORIZ _____		_____		AMP RMS	
VERT. _____		SYM. AVAILABLE			
○ _____		MAX _____		○	
					
87				51139-262-01	

DO NOT DETACH THIS SHEET

MOTOR DATA:

HP \_\_\_\_\_ VOLTAGE \_\_\_\_\_ FULL LOAD CURRENT \_\_\_\_\_

SERVICE FACTOR \_\_\_\_\_ NEMA DESIGN \_\_\_\_\_ SPEED \_\_\_\_\_

APPLICATION DATA:

APPLICATION (DESCRIBE) \_\_\_\_\_


SPEED RANGE: MAX. SPEED \_\_\_\_\_ MIN. SPEED \_\_\_\_\_ DUTY CYCLE \_\_\_\_\_

CONTROLLER TROUBLE SHEET (continued)

PROBLEM INFORMATION:

LED'S THAT ARE ILLUMINATED (MARK ON DRAWING)

NO. OF GATE DRIVER LED'S ON \_\_\_\_\_



LENGTH OF TIME CONTROLLER HAS OPERATED PROPERLY:


\_\_\_\_\_ MONTHS, OR PROBLEM OCCURRED AT START-UP \_\_\_\_\_

DESCRIPTION OF SYMPTOMS \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_

DETAIL TROUBLESHOOTING STEPS TAKEN \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_



\* SEE 10.0 TABLE OF CONTENTS FOR LOCATION.

**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**

TITLE WILL NOT START


CLASS \_\_\_\_\_ TYPE \_\_\_\_\_ FORM \_\_\_\_\_ SER. \_\_\_\_\_  
 DATE DWN. 12-86  
 DATE REL. \_\_\_\_\_  
 DWN. \_\_\_\_\_  
 DRW. NO. \_\_\_\_\_  
 APP'D \_\_\_\_\_  
 CHG. \_\_\_\_\_  
 PROD. NO. \_\_\_\_\_

REV.	DATE	REVISION DESCRIPTION	BY

REF. 880A-7.6  
 DATE DWN. 12-86  
 DATE REL. \_\_\_\_\_  
 DWN. \_\_\_\_\_  
 DRW. NO. \_\_\_\_\_  
 APP'D \_\_\_\_\_  
 CHG. \_\_\_\_\_  
 PROD. NO. \_\_\_\_\_

REF. 880A-7.6  
 DATE DWN. 12-86  
 DATE REL. \_\_\_\_\_  
 DWN. \_\_\_\_\_  
 DRW. NO. \_\_\_\_\_  
 APP'D \_\_\_\_\_  
 CHG. \_\_\_\_\_  
 PROD. NO. \_\_\_\_\_

REF. 880A-7.6  
 DATE DWN. 12-86  
 DATE REL. \_\_\_\_\_  
 DWN. \_\_\_\_\_  
 DRW. NO. \_\_\_\_\_  
 APP'D \_\_\_\_\_  
 CHG. \_\_\_\_\_  
 PROD. NO. \_\_\_\_\_



1. VERIFY MOTOR CURRENT LIMIT (MCL) POTENTIOMETER IS FULLY CLOCKWISE.
2. VERIFY THAT THE VOLTAGE BOOST (E-BOOST) POTENTIOMETER IS ADJUSTED CORRECTLY, PER SECTION 6.0.
3. CHECK FOR PROPER GATING PER 10.4.1\*.
4. PERFORM OUTPUT VOLTAGE CHECK PER 10.4.2\*.
5. VERIFY THAT THE LOAD IS MECHANICALLY FREE TO ROTATE.
6. VERIFY THAT THE STARTING TORQUE REQUIRED DOES NOT EXCEED THE MOTOR/CONTROLLER CAPABILITY.
7. CONSULT LOCAL SQUARE D REPRESENTATIVE.

**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**  
TITLE WILL NOT ACCELERATE  
CLASS TYPE FORM SER.

DATE CHG. 12-93  
DATE REL. 8804-7.6  
DWN. APP'D  
SER. 10.1.2  
SHEET 1 OF 1

REF. 8804-7.6			
ISSN			
PROJ. NO.			




REV. DATE			

REVISION DESCRIPTION			

BY			

\* SEE 10.0 TABLE OF CONTENTS FOR LOCATION.





\* SEE 10.0 TABLE OF CONTENTS FOR LOCATION.

**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**

TITLE ACCELERATES TOO SLOWLY

CLASS TYPE FORM SER. \_\_\_\_\_  
 DATE REC. \_\_\_\_\_  
 DATE ISS. \_\_\_\_\_  
 DATE APP'D \_\_\_\_\_  
 CO. \_\_\_\_\_  
 DRG. NO. **10.1.3**  
 SHEET **MASTER**  
 OF 1

REF. 8804-7.6

NSI  
 PDSN  
 PROD.NO.


REVISION DESCRIPTION

REV. DATE

BY








\* SEE 10.0 TABLE OF CONTENTS FOR LOCATION.

**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**  
TITLE IOC LED ILLUMINATES  
CLASS TYPE FORM SER.

DATE CHG. 12-85  
DATE REL. 8804-7.6  
CON. APP'D  
SER. NO. 10.2.2  
MASTER SHEET  
OF 1

REF. ASSEMBLY	8804-7.6	BY	
PROJ. NO.		REVISION DESCRIPTION	
REV. DATE			



\* SEE 10.0 TABLE OF CONTENTS FOR LOCATION.

**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**

TITLE DV LED ILLUMINATES

CLASS TYPE FORM SER.

DATE CHG. 12-85  
DATE REL. 8804-7.6

DRN. 001  
APP'D

REF. 8804-7.6  
ISSN  
ASSEN  
PROJ. NO.


10.2.3

MASTER

1

REV. DATE REVISION DESCRIPTION BY





**CAD SYSTEM ORIGINAL. DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**

TITLE BUJ LED ILLUMINATES

CLASS TYPE FORM SER.

DATE PREP. 12-85

DATE REL. 8804-7,6

COO. APP'D

DRW. 10.2.5

REF. 8804-7,6

REV. ASSEN

PROD. NO.

MASTER


\* SEE 10.0 TABLE OF CONTENTS FOR LOCATION.

REV.	DATE	BY	REVISION DESCRIPTION









**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**  
TITLE GATING

CLASS TYPE FORM SER  
DATE CHG. DATE REL. DRG. NO. SER. PROJECT  
2-86 8804-3.7.6 MASTER  
DRI. QD. APP'D 10.4.1 2

REV. DATE	BY	REVISION DESCRIPTION	REF. DESIG. PROJ. NO.	8804-3.7.6



NOTE: Any reference to horsepower is at 460V unless stated otherwise. All controllers can be reconnected for 230V or 200V operation as detailed in Section 6.

**CONTENTS**

**11.1 OMEGAPAK 1000 CONTROLLER DIAGRAMS**

- 11.1.1 POWER ELEMENTARY 1-25 HP
- 11.1.2 CONNECTION DIAGRAM 1-25 HP
- 11.1.3 POWER ELEMENTARY 30-50 HP
- 11.1.4 CONNECTION DIAGRAM 30-50 HP
- 11.1.5 CONTROL ELEMENTARY 1-50 HP
- 11.1.6 OUTLINE DIAGRAM 1-25 HP OPEN TYPE
- 11.1.7 OUTLINE DIAGRAM 30-50 HP OPEN TYPE
- 11.1.8 OUTLINE DIAGRAM 1-25 HP ENCLOSED TYPE
- 11.1.9 OUTLINE DIAGRAM 30-50 HP ENCLOSED TYPE

**11.2 CONTROL CIRCUIT ELEMENTARY DIAGRAMS**

- 11.2.1 PILOT LIGHTS, ELAPSED TIME METER, HEAT SINK FAN(S)
- 11.2.2 START-STOP PUSH BUTTONS
- 11.2.3 HAND-AUTO SELECTOR SWITCH AND START-STOP PUSH BUTTONS
- 11.2.4 HAND-OFF-AUTO SELECTOR SWITCH

**11.3 OMEGAPAK 2000 CONTROLLER DIAGRAMS**

- 11.3.1 CONNECTION DIAGRAM 1-25 HP
- 11.3.2 CONNECTION DIAGRAM 1-25 HP W/ISOLATION CONTACTOR
- 11.3.3 CONNECTION DIAGRAM 1-25 HP W/DISCONNECT MEANS
- 11.3.4 CONNECTION DIAGRAM 1-25 HP W/ISOLATION CONTACTOR AND DISCONNECT MEANS
- 11.3.5 CONNECTION DIAGRAM 1-25 HP W/DISCONNECT MEANS AND ISOLATION/BYPASS CONTACTORS
- 11.3.6 CONNECTION DIAGRAM 1-25 HP W/DISCONNECT MEANS AND ISOLATION/BYPASS CONTACTORS
- 11.3.7 CONNECTION DIAGRAM 30-50 HP

11.3.8 CONNECTION DIAGRAM 30-50 HP W/ISOLATION CONTACTOR

11.3.9 CONNECTION DIAGRAM 30-50 HP W/DISCONNECT MEANS

11.3.10 CONNECTION DIAGRAM 30-50 HP W/DISCONNECT MEANS AND ISOLATION/BYPASS CONTACTORS

11.3.11 CONNECTION DIAGRAM 30-50 HP W/ISOLATION CONTACTOR AND DISCONNECT MEANS

11.3.12 ISOLATION CONTACTOR ELEMENTARY AND CONNECTION DIAGRAM 1-50 HP

11.3.13 ISOLATION/BYPASS CONTACTORS ELEMENTARY AND CONNECTION DIAGRAM 1-25 HP

11.3.14 ISOLATION/BYPASS CONTACTORS ELEMENTARY AND CONNECTION DIAGRAM 30-50 HP

11.3.15 OUTLINE DIAGRAM-OMEGAPAK 2000 SINGLE ENCLOSURE

11.3.16 OUTLINE DIAGRAM-OMEGAPAK 2000 DUAL ENCLOSURE

**11.4 OPTIONAL DOOR MOUNTED PILOT DEVICES**

- 11.4.1 Cable routing
- 11.4.2 CONNECTION DIAGRAM MOD. NO. S10 — START-STOP PUSH BUTTONS AND MANUAL SPEED POTENTIOMETER
- 11.4.3 CONNECTION DIAGRAM MOD. NO. A10 — HAND-AUTO SELECTOR SWITCH, START-STOP PUSH BUTTONS AND MANUAL SPEED POTENTIOMETER
- 11.4.4 CONNECTION DIAGRAM MOD. NO. H10 — HAND-OFF-AUTO SELECTOR SWITCH AND MANUAL SPEED POTENTIOMETER
- 11.4.5 DOOR MOUNTED PILOT DEVICE MOUNTING LOCATIONS

**11.5 OPTIONAL REMOTE OPERATOR STATIONS CONNECTION DIAGRAMS**

- 11.5.1 Type CA-31 (Type CA-31R) start-stop push buttons and manual speed potentiometer (reset push button)
- 11.5.2 Type CA-41 (Type CA-41R) start-stop push buttons, run light and manual speed potentiometer (reset push button)

11.5.3 Type CA-42 (Type CA-42R) hand-auto selector switch, start-stop push buttons and manual speed potentiometer (reset push button)

11.5.4 Type CA-65 (Type CA-65R) hand-auto selector switch, start-stop push buttons, run light and manual speed potentiometer (reset push button)


## **11.7 MISCELLANEOUS**

11.7.1 Meter connection diagram

11.7.2 Main control board terminal designation

11.7.3 Main control board block diagram


PRECHARGE RESISTOR ASS'Y  
 52011-127-51 1-5 HP--50n, 10W  
 52011-127-52 7.5-25 HP--20n, 10W



DRIVE H.P.	NO. OF CAP. 90MFD PER CAN (1)	MOTOR CURRENT XFRM RATIO	NO. OF TURNS PRI. SEC.	POWER BLOCKS			INDUCTORS L1 AND L2 STANDARD
				GTD PB1-2-3	DIODES PB4-5-6	DIODES PB7-8	
1	1	200:5	0	52915-028-50	52915-005-52	52914-026-52	51175-048-51
2	1	200:5	0	52915-028-50	52915-005-52	52914-026-52	51175-048-51
3	1	200:5	6	52915-028-50	52915-005-52	52914-026-52	51175-048-51
5	1	200:5	4	52915-028-50	52915-005-52	52914-026-52	51175-048-51
7.5	2	250:5	3	52915-028-50	52915-005-52	52914-026-52	51175-048-51
10	2	300:5	2	52915-028-50	52915-005-52	52914-026-52	51175-048-51
15	3	400:5	2	52915-027-50	52915-005-52	52914-026-52	51175-048-50
20	4	400:5	2	52915-027-50	52915-005-52	52914-026-52	51175-048-50
25	5	500:5	2	52913-027-50	52913-005-52	52914-026-52	51175-048-50

③ GND. FAULT CURRENT TRANSFORMER  
 PRIMARY TURN, 150:5 RATIO FOR ALL H.P.'S  
 L3 AND L4 INDUCTORS ARE A WIRE LOOP CONTAINED  
 IN THE WIRE HARNESS

④ -50 INDUCTOR ASS'Y IS 75 MICROHENRY



TYPICAL THYRISTOR GATING AND SNUBBER CIRCUIT  
 FOR THY1 TO THY6

CAD SYSTEM ORIGINAL.  
 DO NOT CHANGE MANUALLY.

**SQUARE D COMPANY**

TITLE OMEGAPAK VARIABLE TORQUE CONTROLLER  
 POWER ELEMENTARY DIAGRAM (1-25HP)

CLASS TYPE FORM SER.  
 DIV. NO. 2-107  
 DATE 8804-6  
 REFERENCE NEXT ASSN. 111.1  
 REVISION DESCRIPTION

2 . . . . .

13

12

11

10

9

8

7

6

5


4

3

2

1

128.1



CAD SYSTEM ORIGINAL  
DO NOT CHANGE MANUALLY.

**SQUARE D COMPANY**

TITLE VARIABLE TORQUE CONTROLLER  
CONNECTION DIAGRAM (1-25 HP)

CLASS TYPE FORM SER.  
DATE 11.1.2

TRANSFORMER CONNECTIONS


SOURCE VOLTAGE	PRIMARY INPUT	JUMPER
440/460/480	H1 TO H6	H3 TO H4
220/230/240	H1 TO H6	H1 TO H4, H3 TO H6
192/200/208	H1 TO H6	H1 TO H4, H2 TO H6

REV.	DATE	BY	APP. NO.	DESCRIPTION
1			8804-G	
2			2-87	

\* 1-20 HP ONLY  
\*\* 25 HP ONLY


11-4-86

A33



CAD SYSTEM ORIGINAL  
DO NOT CHANGE MANUALLY.


**SQUARE D COMPANY**  
TITLE: MEGAPAK VARIABLE TORQUE CONTROLLER  
POWER ELEMENTARY DIAGRAM (30-50HP)  
CLASS: TYPE: FORM: SER.  
DATE: 11.1.3  
BY: [blank] CHK: [blank] DES: [blank] DWT: [blank]



DRIVE H.P.	NO. OF CAP. CHANS. PER CAN (1)	MTR. CURR. XFMR'S RATIO	NO. OF TURNS		DIODES		INDUCTORS		INPUT FUSE STANDARD
			PRI.	SEC.	PB1-2-3	PB4-5-6	PB7-8	L1 AND L2	
30	6	300:5	1	0	52915-029-50	52915-005-52	52914-026-52	51175-054-50	JUS 100
40	8	400:5	1	0	52915-029-50	52915-005-52	52914-026-52	51175-054-50	JUS 100
50	10	500:5	1	0	52915-029-50	52915-005-52	52914-026-52	51175-054-50	JUS 100

(1) GND. FAULT CURRENT TRANSFORMER  
(2) PRIMARY TURN, 300:5 RATIO FOR ALL H.P.'S  
(3) L3 AND L4 INDUCTORS ARE A WIRE LOOP CONTAINED IN THE WIRE HARNESS





**SQUARE D COMPANY**  
 TITLE ENHANCED VARIABLE TORQUE CONTROLLER  
 CONNECTION DIAGRAM (30-50 HP)  
 CLASS TYPE FORM SER. #  
**MASTER**  
 11-14

**MAIN CONTROL BOARD**  
 (FRONT VIEW PANEL)  
 CAD SYSTEM ORIGINAL.  
 DO NOT CHANGE MANUALLY.


TRANSFORMER CONNECTIONS

SOURCE	PRIMARY	JUMPER
440/460/480	H1 TO H6, H3 TO H4	
220/230/240	H1 TO H6, H1 TO H4, H3 TO H6	
192/200/208	H1 TO H5, H1 TO H4, H2 TO H5	


**(INSIDE VIEW OF DOOR)**

- USED ON 40HP CONTROLLER ONLY.
- JUMPERS CONNECTING CAP A TO CAP B AND CAP D TO CAP E ARE USED ON 30HP CONTROLLERS ONLY.
- USED ON 50HP CONTROLLER ONLY.





BY	
REVISION DESCRIPTION	
REV.	DATE
SHEET	DRG. NO.
11.1.6	



D.B. RESISTOR ASSY  
(IF USED)

▲ SHROUD PROJECTION WITH DOOR OPEN MUST BE CONSIDERED WHEN MOUNTING CONTROLLER NEAR ADJACENT SURFACES.

DUAL DIM. INCHES  
MILLIMETERS

**CAD SYSTEM ORIGINAL  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**  
TITLE 1-20 HP. 25HP VT  
OPEN TYPE OUTLINE  
CLASS \_\_\_\_\_ TYPE \_\_\_\_\_ FORM \_\_\_\_\_ SER. \_\_\_\_\_

REF.	8804-6	DATE DRN.	2-87	DATE REL.		DRG. NO.	MASTER	SHEET
NEXT ASSEM		DRN.		CKD.		APP'D	11.1.6	OF
PROJ. NO.								







11.2.1

13

12

11

10

9

8

7

6

5


4

3

2

1

129.1



CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.

SQUARE D COMPANY

TITLE CONTROL CIRCUIT ELEMENTARY

FAN RELAY, OPTIONAL PILOT LIGHTS

CLASS TYPE FORM SER.

UNIT NO. 11-86

REV. NO. 11.2.1

MASTER

REFERENCE 8804-7.6

REV. 11-86

PROJ. NO.

DATE

BY

REVISION DESCRIPTION

M

N

O

P

Q

K

L

M

N

O

I

J

K

L

M

H

I

J

K

L

F

G

H

I

J

E

F

G

H

I

D

E

F

G

H

C

D

E

F

G

B

C

D

E

F

A

B

C

D

E

6-11-86

AA2







CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.

**SQUARE D COMPANY**

TITLE CONTROL CIRCUIT ELEMENTARY  
MOD A10 HAND-AUTO START-STOP

CLASS. TYPE FORM SER.  
DATE 11-86  
DRAWN BY  
CHECKED BY  
APPROVED BY  
SERIAL NO. 11.2.3


SEE DRAWING 11.2.1



- ① TRANSISTOR IS OFF WHEN CONDITION(S) INDICATED ARE TRUE.
- ② REMOVE JUMPER WHEN BYPASS IC IS USED
- ③ SUPPLIED BY OTHERS. CLOSES TO RUN IN AUTO MODE.
- ④ LOCATED IN ISO-BYPASS OR ISOLATION MODULE (IF USED)







NOTES:

- (1) FOR METER CONNECTIONS REFER TO DWG. 11.7.1.
- (2) JUMPERS WILL ALREADY BE PRESENT IF PILOT DEVICES ARE INSTALLED IN DRIVE CONTROLLER.
- (3) REMOVE JUMPER BETWEEN TERMINALS 41 AND 42.
- (4) USED ON 25 HP VARIABLE TORQUE CONTROLLER ONLY.
- (5) ALL DEVICES SHOWN WITH DASHED LINES ARE TO BE WIRED PER DIAGRAM.
- (6) REFER TO DRAWING 11.3.12 FOR DETAIL.

CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.

**SQUARE D COMPANY**

TITLE 2000 STYLE 1-25 HP CONTROLLER  
ISOL. CONTACTOR

CLASS.	TYPE	FORM	SER.
2-87			MASTER
			11.3.2

REV.	DATE	BY	DESCRIPTION	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T




















11.3.11

13  
12  
11  
10  
9  
8  
7  
6  
5  
4  
3  
2  
1



- NOTES:
- (1) FOR METER CONNECTIONS REFER TO DWG. 11.7.1.
  - (2) JUMPERS WILL ALREADY BE PRESENT IF PILOT DEVICES ARE INSTALLED IN DRIVE CONTROLLER.
  - (3) REMOVE JUMPER BETWEEN TERMINALS 41 AND 42.
  - (4) USED ON 50HP VARIABLE TORQUE CONTROLLERS ONLY.
  - (5) MAKE CONNECTIONS AT POWER TERMINAL BLOCK WHEN FUSIBLE DISCONNECT IS SUPPLIED.
  - (6) BUNDLE THESE WIRES TOGETHER AND KEEP SEPARATE FROM OTHER POWER AND CONTROL WIRES.
  - (7) ALL DEVICES SHOWN WITH DASHED LINES ARE TO BE WIRED PER DIAGRAM, IF USED.
  - (8) REFER TO DRAWING 11.3.12 FOR DETAIL.

**CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**

TITLE 2000 STYLE 30-50HP CONTROLLER.  
SINGLE DISC... ISOL. CONTACTOR

CLASS. TYPE FORM SER. REV. NO. 11.3.11

DATE 2-87

BY [signature]

CHKD [signature]

APPD [signature]

PROJ. NO. [blank]

REV. DATE [blank]

DESCRIPTION [blank]

REFERENCE [blank]

NET USER [blank]





BT

8804-6

11.3.11

MASTER

A B C D E F G H I J K L M N O P Q R S T



WIRE TABLE		DEVICE DESIGNATION	
WIRE NO	SIZE AND COLOR		
1	16 GA RED	T4, FU2	
2		T4, FU3	
3		T4, H1	
4		IC, T8	
5		IC, T8	
6		GND, SCR, T4, IC	
7		IC, T8	
8		IC, T8	
16		IC, T8	

TRANSFORMER CONNECTIONS		
SOURCE VOLTAGE	PRIMARY INPUT	SECONDARY OUTPUT JUMPER
440/460/480	H1 TO H4, X1 TO X2	H2 TO H3
220/230/240	H1 TO H4, X1 TO X2	H1 TO H3, H2 TO H4
192/200/208	H1 TO H4, X1 TO X3	H1 TO H3, H2 TO H4

CAD SYSTEM ORIGINAL.  
DO NOT CHANGE MANUALLY.

**SQUARE D COMPANY**

TITLE ISOLATION CONTACTOR (1-50 HP)

CLASS 8804 TYPE \_\_\_\_\_ FORM \_\_\_\_\_ SER. \_\_\_\_\_  
 DATE NO. \_\_\_\_\_  
 REV. NO. \_\_\_\_\_  
 11.3.12  
**MASTER**




- NOTES:
- △ LOCATED IN ADJUSTABLE FREQUENCY CONTROLLER
  - ( ) INDICATES TERMINAL NUMBER ON DEVICE
  - △ 460V TRANSFORMER CONNECTIONS SHOWN FOR OTHER VOLTAGES. SEE TRANSFORMER CONNECTION TABLE









DIMENSIONS	A	B	C	D	E
D.B. RESISTORS (IF USED)	8.65 (219.7)	76.2 (226.0)	5.82 (147.8)	1.68 (42.7)	1.64 (41.7)
TURRET VENT (IF USED)	10.0 (254.0)	34.1 (866.0)	147.8 (3748.0)	147.8 (3748.0)	147.8 (3748.0)

**CAD SYSTEM ORIGINAL. DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**  
 TITLE: OUTLINE DRAWING  
 SERIES: 2000 CAB  
 CLASS: TYPE FORM SER.


DATE: 2-87  
 DATE REL. 11.3.15  
 Dwg. No. 11.3.15  
 SHEET 1 of 1

REV.	DATE	REVISION DESCRIPTION	BY

REF. 8804-6  
 PROJ. NO. 11.3.15







BY	
REVISION DESCRIPTION	
REV. DATE	
SHEET	11.4.2
DRG. NO.	11.4.2
OF	

MOD. NO. S10

**CAD SYSTEM ORIGINAL  
DO NOT CHANGE MANUALLY.**


**SQUARE D COMPANY**

TITLE CONNECTION DIAGRAM  
START-STOP, MAN. SPD.

CLASS \_\_\_\_\_ TYPE \_\_\_\_\_ FORM \_\_\_\_\_ SER. \_\_\_\_\_

REF.	8804-7.6	DATE DRN.	11-86	DATE REL.		DRG. NO.	<b>MASTER</b>	SHEET
NEXT ASSEM.		DRN.		CKD.		APP'D	11.4.2	OF
PROJ. NO.								





BY						
	REVISION DESCRIPTION					
REV. DATE						
SHEET						
DRG. NO.	11.4.4					


**CAD SYSTEM ORIGINAL  
DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**  
 TITLE CONNECTION DIAGRAM  
 HAND-OFF-AUTO, MAN. SPEED  
 CLASS \_\_\_\_\_ TYPE \_\_\_\_\_ FORM \_\_\_\_\_ SER. \_\_\_\_\_

REF.	8804-7,6	DATE DRN.	11-86	DATE REL.		DRG. NO.	MASTER	SHEET
NEXT ASSEM.		DRN.		CKD.		APP'D	11.4.4	OF
PROJ. NO.								

A B C D E F

8  
7  
6  
5  
4  
3  
2  
1



POWER ON -MOD. NO. P16  
 RUN -MOD. NO. R16  
 DRIVE FAIL -MOD. NO. F16

**CAD SYSTEM ORIGINAL  
 DO NOT CHANGE MANUALLY.**

**SQUARE D COMPANY**

TITLE CONNECTION DIAGRAM  
 DOOR MOUNTING PILOT LIGHTS  
 CLASS TYPE FORM SER.

BY	
REVISION DESCRIPTION	
REV. DATE	

LEBHS  
 11.4.5  
 DRG. NO.

REF.	8804-7.6	DATE DRN.	11-86	DATE REL.		DRG. NO.		SHEET	
NEXT ASSEM.		DRN.		CRD.		APP'D			
PROJ. NO.						11.4.5	MASTER	OF	











MANUAL SPEED, START-STOP, HAND-AUTO, "RUN" PILOT LIGHT (RESET) ①



ADJUSTABLE FREQUENCY CONTROLLER (FRONT VIEW)



LOW LEVEL CONTROL WIRING. THESE CONDUITS MAY BE ROUTED IN THE SAME PLACE WITH WIRING. SEPARATION (CONDUIT) OR 12" SEPARATION (TRAY) FROM OTHER TYPES OF POWER OR CONTROL WIRING. ALL CONDUCTORS TO BE #18 AWG MINIMUM. SHIELDED CABLE TO BE JACKETED, GROUND SHIELD ONLY WHERE SHOWN. INSULATE OTHER END OF SHIELDED CABLE.

① USED ON CA-6SR CONTROL STATION ONLY.

CAD SYSTEM ORIGINAL  
DO NOT CHANGE MANUALLY.

SQUARE D COMPANY

TITLE CONNECTION DIAGRAM TYPE CA-6S &  
CA-6SR REMOTE OPERATOR STATION

CLASS TYPE FORM SER.  
DATE 11-86  
DRAWN BY  
CHECKED BY  
APPROVED BY  
11.5.4  
MASTER

REFERENCE	REV. NO.	ISSUE DATE	DESCRIPTION
8804-7,6	11-86		

11.7.11

13

12

11

10

9

8

7

6

5


4

3


2

1793

MAIN CONTROL PWB (DETAIL) TB1



MAIN CONTROL PWB (DETAIL) TB1



CAD SYSTEM ORIGINAL. DO NOT CHANGE MANUALLY.

SQUARE D COMPANY

TITLE\_METER CONNECTION DIAGRAM

CLASS TYPE FORM SER.

DATE REC. 11.7.11

DATE SER. 11.7.11

REF. NO. 8804-3.1.7.6

REV. NO. 1

PROJ. NO. 11.7.11

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

A B C D E F G H I J K L M N O P Q R S T





## 12.0 RENEWAL PARTS LIST

DESCRIPTION	PART NUMBER		
	1-10 HP <sup>①</sup>	15-25 HP <sup>①</sup>	30-50 HP <sup>①</sup>
Main Control Board	52011-395-50	52011-395-50	52011-395-50
Gate Driver Board	52011-003-50	52011-003-50	52011-003-50
Power Interface Board	52011-005-51	52011-005-50	52011-028-50
Fuse (24V Control, Primary — FU6, FU7) KTK-10	25419-10141	25419-10141	25419-10141
Fuse (Line — FU3, FU4, FU5)	25499-00654	25499-00654	25499-00655
Fuse (Main Control Board — FU1, FU2) MDL-5.0	25420-30500	25420-30500	25420-30500
DC Bus Capacitor	52904-018-50	52904-018-50	52904-018-50
Rectifier	52915-005-52	52915-005-52	52915-005-52
GTO	52915-028-50	52915-027-50	52915-029-50
Flyback Diode	52914-026-52	52914-026-52	52914-026-52
Precharge Contactor	52905-024-50	52905-024-50	52905-024-50
Precharge Resistor Assy.	52011-127-51	52011-127-52	52011-127-52
	(1-5 HP)	(7½-25 HP)	

① Horsepower Rating at 460v

