


Notice

Do not push strongly on the External I/O or External INPUT interface buttons with a pointed object. The buttons may become stuck in the unit, and you may not be able to use the interface.



- A 6-terminal interface is shown here. The number of interface terminals varies by camera model.