



1332-MOD-G4

BCD Interface

Description The BCD Interface Option, MOD-G4, accepts digital signals from a programmable controller or computer in a Binary Coded Decimal (BCD) format and generates frequency (speed) and direction (forward/reverse) signals for a single Bulletin 1332 Adjustable Frequency Drive. Provisions are included to connect the BCD signals through a terminal block suitable for discrete wires or through a 40 pin ribbon cable connector. The ribbon cable connector input is suitable for use on multiplexed systems for independently controlling the speeds of up to 20 Drives.

Specifications

Power Source

- 230V AC, single-phase power is required to operate the control logic and outputs of the BCD Interface Board.
- Remote +5V power source (Customer Supplied), +5.25V DC, $\pm 5\%$, 50mV P-P ripple (maximum), 0.5A (minimum).

IMPORTANT: The BCD Interface Board has an integral power supply monitor for the customer supplied +5 V DC power source. If the power supply voltage drops below 4.75V DC, the board is inhibited from accepting any new data until the voltage is restored to acceptable levels. This prevents the board from responding to unintelligible or incorrect data caused by a decaying power supply.

Control Inputs

- Digital Frequency Inputs: 5V TTL logic level, low equals true logic in a BCD format. Up to 13 inputs may be required based on the resolution of frequency control desired.
- Direction: If direction control is desired, one 5V TTL logic level input is required. Low equals true (reverse) logic.
- Strobe: A 5V TTL logic level is required to signal the board to read the data presented to it (strobing). Low equals true logic.
- Sinking Current: Each TTL input will be required to "sink" approximately 20mA when the board is strobed.

Specifications
(Continued)

Optional Inputs

- Manual Speed Pot: 10k ohm, 2W, customer supplied
- Forward/Reverse Selector Switch: Customer supplied
- Remote Manual/Auto Selection: A customer supplied 120V AC input can be accepted for Remote Manual/Auto operation selection.

Outputs

- Direction: The BCD Interface option has a solid-state contact output which connects to the standard Bulletin 1332 Drive for direction control.
- Frequency: The BCD Interface Board generates a 0 to +10V DC signal based on the input, for use as the frequency (speed) input to the Bulletin 1332 Drive.

IMPORTANT: The Bulletin 1332 has a 20 to 1 speed range. This means that the Drive has a minimum frequency output even when receiving a zero speed command. Because of this, the BCD Interface Board has been designed to ignore speed commands in the first 5% of selected speed range.

Example

Maximum speed range of 60 Hz is selected.

Actual Drive output frequency will be from 3 to 60 Hz.

BCD Interface Board output will be from 0-10V (3-60 Hz).

A BCD input command from 0.0 to 3.0 Hz applied to the BCD Interface Board will not change the output.

However, a BCD input command above 3.0 Hz will change the output accordingly, as shown below.

BCD Input (Hz)	Interface Board Output (volts)	Bulletin 1332 Output (Hz)
0.0	0.000	3.0
3.0	0.000	3.0
3.1	0.017	3.1
10.0	1.228	10.0
60.0	10.000	60.0

Description of Operation

The BCD Interface Board generates an analog signal suitable for speed control of the Bulletin 1332 Drive. In addition, a direction control signal can also be generated for the Drive.

Several modes of operation exist when using the BCD Interface option:

- ▶ Remote Automatic (BCD) Control
- ▶ Remote Manual Control
- ▶ Local Manual Control

Remote Automatic (BCD) Control

When the Bulletin 1332 Drive is switched to Remote input and the BCD Interface Board is in the Automatic mode, the frequency output of the Drive is determined by the BCD data. The board can accept up to 13 bits of frequency data to control the Drive frequency up to 200 Hz in 0.1 Hz increments. The data is received in a BCD format such that four bits determine the value of each decade of frequency information as shown below.

Frequency Decade	Data Bits
0.1 Hz	4 bits (.8 - .4 - .2 - .1)
1.0 Hz	4 bits (8 - 4 - 2 - 1)
10.0 Hz	4 bits (80 - 40 - 20 - 10)
100.0 Hz	1 bit (100)
	<hr style="width: 20%; margin: 0 auto;"/>
	13 bits total

In addition to the frequency data listed above, one "strobe" bit is required to signal the board to read the frequency data at the input lines. The strobe requirement prohibits the board from reading data until the strobe is applied. This permits the frequency data at the input to be changed without the BCD Interface Board or the Drive responding to the change.

Example

Assume that the existing Drive frequency is 60 Hz and the desired frequency is 100 Hz.

It's possible that:

The input data could be 160 Hz if the 100 Hz bit was present before the 60 Hz bits were removed.

OR

The data could be 0 Hz if the 60 Hz bits were removed before the 100 Hz bit was present.

Description of Operation
(Continued)

Control of the strobe permits the Interface Board and Drive to ignore any undesired combinations.

Once the desired frequency data is present at the input, the strobe is applied which signals the board to read the data. The board then loads the data into a storage buffer for memory. The stored data is internally fed to a precision digital to analog (D/A) converter which in turn generates a 0 to 10V DC output (speed reference) signal for the Drive.

In addition to frequency data, there are provisions for the board to read one separate input data bit to control direction. When this bit is set, it is read along with the frequency data and stored. A separate circuit monitors this bit and controls a solid-state switch which is connected to the direction control terminals of the Drive. The option can now control the forward or reverse operation of the Drive as follows:

Direction Bit	Direction
"0" (False = High)	Forward
"1" (True = Low)	Reverse

When power is first applied to the BCD Interface Board or the board is switched to Manual Control, the storage buffer is erased to reset the buffer and start out with a loaded frequency of zero and a forward direction.

Remote Manual Control

The BCD Interface Board has provisions for switching to a Remote Manual mode of operation through the use of a selector switch located on the board or a customer supplied 120V, single-phase, 60 Hz AC input signal. When in Manual, a remote manual speed pot and remote forward/reverse selector switch (if direction control is desired) is required. In the Remote Manual mode, the D/A converter is disabled and the remote manual speed pot is used for the speed output signal. Internal circuits generate a power supply for the speed pot and select which signal is fed to the Drive. The BCD input for direction control is also ignored in this mode, with the remote forward/reverse selector switch monitored to determine direction of Drive rotation.

Description of Operation
(Continued)

Local Manual Control

All outputs of the BCD Interface Board will be ignored if the Bulletin 1332 Drive is switched from Remote to Local at the Local Operator Panel of the Drive.

When in the Local mode, the Bulletin 1332 will respond to the speed pot and forward/reverse selector switch located at the local operator's station. Refer to the *Bulletin 1332 Instruction Manual* for further information.

Start/Stop Operation

IMPORTANT: In all cases the start/stop operation of the Drive is controlled at the Drive. The BCD Interface Board does not perform any start/stop commands. However, the method of controlling the start and stop of the Drive may be affected by the desired mode of operation of the BCD Interface Board. Refer to the *Bulletin 1332 Instruction Manual* for further information.

The Bulletin 1332 Drive uses the same local/remote selector switch to change the forward/reverse direction and start/stop control from the local operators station to the remote inputs. To accept the BCD Interface Board direction commands, the switch must be in the Remote position. When this is done, other provisions (remote start/stop) must be made to start and stop the Drive. The Drive local/remote frequency selector switch is independent of the local/remote direction and start/stop selector switches. Therefore, it is possible to have the Drive accept the BCD Interface Board speed commands while also accepting the local commands for start/stop and direction.

Operation

Table A provides a listing of the Drive and BCD Interface Board switch positions and the resultant operation.

Table A
Bulletin 1332 Operation

Drive Switch Settings		BCD Board	
SW3 <i>Local/Remote</i>	SW4 <i>Local/Remote</i>	S1 <i>Manual/Auto</i>	Operation
Local	Local	Ignored	Speed, Direction and Start are controlled by the Local Operator Panel of the Drive (SW1, SW2 & frequency pot).
Local	Remote	Auto	Speed is controlled by the BCD input. Direction, Start and Stop are controlled by the Local Operator Panel (SW1 & SW2).
Local	Remote	Manual	Speed is controlled by the Remote Manual speed pot. Direction and Start by the Local Operator Panel.
Remote	Remote	Auto	Speed and Direction are controlled by BCD inputs. Start/stop controlled by inputs to the Drive Control Terminal Block.
Remote	Remote	Manual	Speed and Direction are controlled by Remote Manual inputs. Start/Stop controlled by inputs to the Drive Control Terminal Block.

Adjustments

IMPORTANT: All potentiometers located on the BCD Interface Board are factory sealed and pre-calibrated. Field adjustment is **not** required.

A scaling jumper located on the BCD Interface Board (see Figure 1) is used to match the board output to the frequency range selected in the Drive. To ensure proper operation, the jumper should be set as described in Table B.

Table B
Scaling Jumper Setting

Frequency Range	DSW2 Switch Settings <i>Bulletin 1332 (SW1, SW2, SW3)</i>		Jumper Setting <i>BCD Interface Board</i>
3 to 60 Hz	3 to 60 Hz	(off-off-off)*	60 Hz
6 to 120 Hz	6 to 120 Hz	(off-on-off)*	120 Hz
12 to 200 Hz	12 to 240 Hz	(off-off-on)*	200 Hz

* Refer to the Bulletin 1332 Instruction Manual for DSW2, SW4 settings.

IMPORTANT: The Bulletin 1332 is capable of a maximum frequency of 240 Hz. The format of the BCD interface only permits a maximum input of 199.9 (200) Hz. The output of the board is scaled to the appropriate level in the 200 Hz range to produce a maximum output of 200 Hz at the Drive, when operating in the 240 Hz range.




Figure 1 – Scaling Jumper and Switch Locations

Adjustments
(Continued)

IMPORTANT: The Bulletin 1332 has a 20 to 1 speed range. This means that the Drive has a minimum frequency output even when receiving a zero speed command. Because of this, the BCD Interface Board has been designed to ignore speed commands in the first 5% of the selected speed range. Refer to the example presented on page 2 for further explanation.

Installation

The BCD Interface Board is supplied as a loose board for customer mounting. Included with the board are four $\frac{1}{4}$ turn Nylock standoffs to aid in mounting the board.

Installation requires that the board be mounted a maximum of three (3) feet from the Drive.

Mounting Instructions

1. Remove input power from the Drive.
2. Locate the area where the BCD Interface Board is to be mounted.
3. Using the dimensions provided in Figure 2, mark the location of the holes to be drilled.

Installation
(Continued)




Figure 2 – BCD Interface Board Dimensions

4. Drill four (4) - $\frac{1}{4}$ " (6.35mm) holes at the locations marked in the previous step.
5. Insert the standoffs into the holes.
6. Install the board onto the standoffs and lock in place. Refer to Figure 3.

$\frac{1}{4}$ - Turn Standoff

Press down on hex-head of
standoff to lock standoff in
panel.




Figure 3 – Board Installation

7. Wire the option as described in the following section.

Wiring



WARNING: To avoid a shock hazard, ensure that all power has been removed to the Drive before performing the following connections.

Prior to wiring the BCD signals, wiring between the Drive and BCD Interface Board should be performed. Refer to Figure 4 for these connections.



WARNING: Incorrect polarity of remote inputs may cause personal injury from uncontrolled machine motion. Connect remote inputs (terminals 4 & 5 of the Drive) only as shown in Figure 4.

The BCD signals can be connected through a terminal block suitable for discrete wires or through a 40 pin ribbon cable connector. The ribbon cable connector input is suitable for use on multiplexed systems for separately controlling the speeds of up to 20 Drives. A description of each version follows.

Terminal Block Wiring - TB1

Refer to Figure 5 for a diagram of TB1 and the signal designations for the terminal block. Refer to Figure 8 for the typical interconnect drawing and wiring requirements.




Figure 4 – Interconnection Diagram




Figure 5 – TB1 Signal Designations

Wiring
(Continued)

Ribbon Cable Termination

The BCD input data is terminated at a 40 pin ribbon cable connector (3M part number 3417-6040 or equivalent) which plugs into connector J1, of the BCD Interface Board. The ribbon cable permits up to 20 Drives to be controlled from data delivered by one cable having 20 strobe lines. The board has a set of jumpers (labeled J2) that select which one of the 20 strobcs the board will use as its strobe input.

Do not make any connections at TB1 when connections are made at the ribbon cable connector.

IMPORTANT: Only one Drive should be strobed at any time. Ensure that each Drive has its own unique strobe.

Wiring
(Continued)

The pin connections for J1 and strobe select jumpers for J2 are shown in Table C.

Table C
Ribbon Cable Connections

J1 Pin Number	Description	J2 Jumper Position
1	Strobe, Drive # 1	1-2
2	Strobe, Drive # 2	3-4
3	Strobe, Drive # 3	5-6
4	Strobe, Drive # 4	7-8
5	Strobe, Drive # 5	9-10
6	Strobe, Drive # 6	11-12
7	Strobe, Drive # 7	13-14
8	Strobe, Drive # 8	15-16
9	Strobe, Drive # 9	17-18
10	Strobe, Drive # 10	19-20
11	Strobe, Drive # 11	21-22
12	Strobe, Drive # 12	23-24
13	Strobe, Drive # 13	25-26
14	Strobe, Drive # 14	27-28
15	Strobe, Drive # 15	29-30
16	Strobe, Drive # 16	31-32
17	Strobe, Drive # 17	33-34
18	Strobe, Drive # 18	35-36
19	Strobe, Drive # 19	37-38
20	Strobe, Drive # 20	39-40
21	+ 5V Supply	
22	+ 5V Supply	
23	100 Hz Data Input	
24	Direction Data Input (Fwd/Rev)	
25	Not Used	
26	Not Used	
27	Not Used	
28	Not Used	
29	0.1 Hz Data Input	
30	0.2 Hz Data Input	
31	0.4 Hz Data Input	
32	0.8 Hz Data Input	
33	1 Hz Data Input	
34	2 Hz Data Input	
35	4 Hz Data Input	
36	8 Hz Data Input	
37	10 Hz Data Input	
38	20 Hz Data Input	
39	40 Hz Data Input	
40	80 Hz Data Input	

Application of BCD Input

Programming should be arranged such that frequency and direction data are selected 10ms prior to the strobe signal and remain stable for 10ms after the strobe signal is initiated. This interval allows sufficient time for adequate debouncing and filtering of the data lines.

The BCD interface circuit responds to the negative going edge of the strobe signal (TTL output turning ON, pulling LOW towards common). After 10ms the frequency and direction data may be changed prior to the releasing of the strobe signal without affecting data previously stored. Refer to Figure 6.




Figure 6 – Timing Diagram

IMPORTANT: Strobe is typically pulsed at a rate much faster than data is updated.

**Operation with an
Allen-Bradley
Programmable Controller**

The Bulletin 1771-0G TTL Output Modules available for use in Allen-Bradley Programmable Controllers are ideal outputs for use with the BCD Interface.

Both 1771-0G TTL Modules must be set up for the LOW = True logic format by setting internal switches to the OFF position as shown in Figure 7.




Figure 7 – Logic Switch Positions

For ease in programming, the 1771-0G TTL Output Modules should be located in the same module group of the programmable controller I/O chassis to furnish consecutive data bits from terminals 00-07 and 10-16. Drive frequency is defined from 000.0 Hz to 199.9 Hz in 0.1 Hz increments by terminals 00-07 and 10-14. Terminal 15 defines motor direction (forward/reverse) and terminal 16 is the strobe signal which triggers the time at which the frequency and direction data is read by the BCD interface circuit. Status indicator lights on the 1771-0G TTL Output Modules show LOW = True condition for each terminal.

Figure 8 shows typical connections between the BCD Interface Board and an Allen-Bradley Programmable Controller with 1771-0G, TTL Output Modules. A sample PC program follows the interconnect drawing in Figure 9.




Figure 8 - Typical Interconnect Drawing with an Allen-Bradley Programmable Controller

FUNCTION: Changes data every 5 seconds, strobe for 10ms at 50ms intervals. The motor changes speed or direction every 5 seconds in the following sequence:
0 Hz, + 30 Hz, + 60 Hz, 0 Hz, -30 Hz, -60 Hz, 0 Hz

INSTRUCTION			DESCRIPTION
03015	}/ {		030 (TON) --- Data Timing 1.0 PR 028 AC xxx
030 xxx	050 { = } 001	040 { G } 300	043 (PUT) --- 30 Hz – Frequency Data
030 xxx	051 { = } 005	041 { G } 600	043 (PUT) --- 60 Hz – Frequency Data
030 xxx	052 { = } 010	042 { G } 000	043 (PUT) --- 0 Hz – Frequency Data ①
030 xxx	053 { = } 015	040 { G } 300	043 (PUT) --- 30 Hz – Frequency Data
030 xxx	054 { = } 020	041 { G } 600	043 (PUT) --- 60 Hz – Frequency Data
030 xxx	055 { G } 025	042 { G } 000	043 (PUT) --- 0 Hz – Frequency Data ①
052 010	030 { < } xxx		04015 () --- } Direction Data (REVERSE at 10 Seconds)
04015	}/ {		04115 ()
03115	}/ {		031 (TON) --- Strobe Timing 0.01 PR 005 AC yyy
031 yyy	050 { = } 001	043 { G } yyy	016 (PUT) --- Data Output
031 yyy	056 { = } 002		01616 () --- Strobe Output

① A 0 Hz frequency command actually results in a typical 3 Hz Drive output frequency. See the Example presented on page 2.

Figure 9 – Sample Program

Notes

Notes



ALLEN-BRADLEY
A Rockwell International Company

Drives Division
Cedarburg, Wisconsin 53012-0005